


User Manual
English

Stratos Pro A2.. MSCOND

Conductivity Measurement With Memosens Sensors



About This Manual.

Return of products

Please contact our Service Team before returning a defective device. Ship the cleaned device to the address you have been given. If the device has been in contact with process fluids, it must be decontaminated/disinfected before shipment. In that case, please attach a corresponding certificate, for the health and safety of our service personnel.


Disposal

Please observe the applicable local or national regulations concerning the disposal of “waste electrical and electronic equipment”.

About this manual:

This manual is intended as a reference guide to your device – You don't have to read the book from front to back. Take a look at the **Table of Contents** or the **Index** to find the function you are interested in. Each topic is explained on a double-page spread with step-by-step instructions on how to configure the desired function. Clearly legible page numbers and headlines help you to quickly find the information:

Left page:
How do I get to the function



Right page:
Which settings are provided for this function

Specific Test Report



CD-ROM

Complete documentation:

- User manuals
- Safety instructions
- Certificates
- Quickstart guides



Safety Instructions


In official EU languages and others.

- EC Declarations of Conformity



Safety Instructions

- Installation and Use
in Hazardous Locations
(shipped with hazardous-area devices only)



Quickstart Guide

First steps after installation:

- Operation
- Menu structure
- Calibration
- Error messages and recommended actions

In German, English, French, Spanish, Portuguese, and Italian.

More languages on CD-ROM and on our website: www.knick.de

Contents

Documents Supplied	3
Introduction	7
Intended Use	7
Safety Information	10
Overview of Stratos Pro A2... MSCOND.....	11
Assembly	12
Package Contents	12
Mounting Plan, Dimensions	13
Pipe Mounting, Protective Hood.....	14
Panel Mounting	15
Installation	16
Installation Instructions.....	16
Rating Plates / Terminal Assignments	16
Wiring of Stratos Pro A2... MSCOND	17
Connecting a Memosens Sensor	19
User Interface, Keypad	20
Display	21
Signal Colors (Display Backlighting)	21
Measuring Mode	22
Selecting the Mode / Entering Values.....	23
Color-Coded User Interface	25
Operating Modes.....	26
Menu Structure of Modes and Functions	27
HOLD Mode	28
Alarm	29
Alarm and HOLD Messages.....	30
Configuration	32
Menu Structure of Configuration.....	32
Manual Switchover of Parameter Sets A/B.....	34
Configuration (Original for Copy)	39
Sensor.....	42
Sensor Verification (TAG, GROUP).....	48

Current Output 1	50
Current Output 2.....	60
Temperature Compensation.....	62
CONTROL Input	66
Alarm Settings.....	68
Time and Date.....	72
Measuring Points (TAG/GROUP)	72
Digital Sensors	74
Operation.....	74
Connecting a Digital Sensor	75
Replacing a Sensor	76
Calibration	79
Selecting a Calibration Mode	79
Calibration with Calibration Solution.....	80
Calibration by Entry of Cell Constant	82
Product Calibration	83
Temp Probe Adjustment	85
Measurement	86
Diagnostics	87
Service	92
USP Function	95
Operating States.....	96
A2...X: Supply Units and Connection.....	97
Product Line and Accessories	98
Specifications	99
Calibration Solutions	105
Concentration Measurement	107
Concentration Curves.....	108
Error Handling.....	114
Error Messages.....	115
Sensoface	117

Contents

- FDA 21 CFR Part 11119**
 - Electronic Signature – Passcodes.....119
 - Audit Trail.....119
- Index120**
 - Trademarks.....127
- Passcodes128**

Intended Use

Stratos Pro A2... MSCOND is a 2-wire device for measurement of electrical conductivity and temperature in liquids using Memosens sensors. Fields of application are: biotechnology, chemical industry, environment, food processing, water/wastewater treatment.

Enclosure and mounting possibilities

- The sturdy molded enclosure is rated IP 67/NEMA 4X for outdoor use. It is made of glass-reinforced PBT / PC and measures 148 mm x 148 mm x 117 mm (H x W x D). It is provided with knockouts to allow:
 - wall mounting (with sealing plugs to seal the enclosure), see page 13
 - post/pipe mounting (Ø 40 ... 60 mm, □ 30 ... 45 mm) see page 14
 - panel mounting (138 mm x 138 mm cutout to DIN 43700), see page 15

Weather protector (accessory)

The weather protector, which is available as accessory, provides additional protection against direct weather exposure and mechanical damage, see page 14.

Connection of sensors, cable glands

For connecting the cables, the enclosure provides

- 3 knockouts for cable glands M20x1.5
- 2 knockouts for NPT 1/2" or rigid metallic conduit

For quasi-stationary installations with Memosens sensors, we recommend using the M12 device socket (accessory ZU 0822) instead of a cable gland – it allows simple replacement of the sensor cable without opening the device.

Sensors

The device has been designed for Memosens 2-electrode sensors.

Display

Plain-text messages in a large, backlit LC display allow intuitive operation. You can specify which process variables are to be displayed in standard measuring mode ("Main Display", see page 24).

Color-coded user interface

The colored display backlighting signals different operating states (e.g. alarm: red, HOLD mode: orange, see page 25).

Diagnostics functions

"Sensocheck" automatically monitors sensor and cables; and the "Sensoface" function clearly indicates the sensor condition, see page 117.

Data logger

The internal logbook (TAN SW-A002) can handle up to 100 entries – up to 200 with AuditTrail (TAN SW-A003), see page 90.

2 parameter sets A, B

The device provides two parameter sets which can be switched manually or via a control input for different process adaptations or different process conditions.

For overview of parameter sets (table for copy), see page 40.


Password protection

Password protection (passcodes) for granting access rights during operation can be configured, see page 94.

TC process medium: Selecting the compensation method

The following temperature compensation methods are provided: linear (by entering a temperature coefficient), natural waters (nLF), NaCl, HCl, NH₃, NaOH, see page 62.

Control inputs



I input

The analog (0) 4 ... 20 mA current input can be used for external temperature compensation (TAN required). See page 64.

HOLD

(floating digital control input)
The HOLD input can be used for external activation of the HOLD mode, see page 29.

CONTROL

(floating digital control input)
The CONTROL input can be used either for parameter set selection (A/B) or for flow monitoring, see page 66.

Signal outputs

The device provides two current outputs (for transmission of measured value and temperature, for example). The output curve is adjustable (linear, bilinear or logarithmic), see page 50 et seq.

Options

Additional functions can be activated by entering a TAN (page 94).

Safety Information

Be sure to read and observe the following safety instructions!

The device has been manufactured using state of the art technology and it complies with applicable safety regulations.

When operating the device, certain conditions may nevertheless lead to danger for the operator or damage to the device.

See also the following documents (page 3):

- "Safety Instructions"
- "Safety Instructions / Installation and Use in Hazardous Locations"



CAUTION!

Commissioning must only be performed by trained personnel authorized by the operating company! Whenever it is likely that protection has been impaired, the device shall be made inoperative and secured against unintended operation.

The protection is likely to be impaired if, for example:


- the device shows visible damage
- the device fails to perform the intended measurements
- after prolonged storage at temperatures below $-30\text{ }^{\circ}\text{C}$ / $-22\text{ }^{\circ}\text{F}$ or above $+70\text{ }^{\circ}\text{C}$ / $+158\text{ }^{\circ}\text{F}$
- after severe transport stresses

Before recommissioning the device, a professional routine test must be performed. This test must be carried out at the manufacturer's factory.

Note:

Before commissioning you must prove that the device may be connected with other equipment.

Overview of Stratos Pro A2... MSCOND



Assembly

Package Contents

Check the shipment for transport damage and completeness!

The package should contain:

- Front unit, rear unit, bag containing small parts
- Specific test report
- Documentation (cf p. 3)
- CD-ROM




Fig.: Assembling the enclosure

- | | |
|---|--|
| 1) Jumper (3 x) | 6) Sealing insert (1 x) |
| 2) Washer (1 x), for conduit mounting: Place washer between enclosure and nut | 7) Rubber reducer (1 x) |
| 3) Cable tie (3 x) | 8) Cable gland (3 x) |
| 4) Hinge pin (1 x), insertable from either side | 9) Filler plug (3 x) |
| 5) Enclosure screw (4 x) | 10) Hexagon nut (5 x) |
| | 11) Sealing plug (2 x), for sealing in case of wall mounting |

Mounting Plan, Dimensions





Fig.: Mounting plan (All dimensions in mm!)

Pipe Mounting, Protective Hood



- 1) Hose clamp with worm gear drive to DIN 3017 (2 x)
- 2) Pipe-mount plate (1 x)
- 3) For vertical or horizontal posts or pipes
- 4) Self-tapping screw (4 x)

Fig.: Pipe-mount kit, accessory ZU 0274 (All dimensions in mm!)





Fig.: Protective hood for wall and pipe mounting, accessory ZU 0737 (All dimensions in mm!)

Panel Mounting



- 1) Circumferential sealing (1 x)
- 2) Screws (4 x)
- 3) Position of control panel
- 4) Span piece (4 x)
- 5) Threaded sleeve (4 x)

Cutout
138 x 138 mm (DIN 43700)

Fig.: Panel-mount kit, accessory ZU 0738 (All dimensions in mm!)

Installation

Installation Instructions

- Installation of the device must be carried out by trained experts in accordance with this user manual and as per applicable local and national codes.
- Be sure to observe the technical specifications and input ratings during installation!
- Be sure not to notch the conductor when stripping the insulation!
- The supplied current must be galvanically isolated. If not, connect an isolator module.
- All parameters must be set by a system administrator prior to commissioning!

Terminals:

suitable for single wires / flexible leads up to 2.5 mm² (AWG 14)

Rating Plates / Terminal Assignments




Fig.: Terminal assignments of Stratos Pro A2...





Fig.: Stratos Pro A2...N rating plate at outside bottom of front

Wiring of Stratos Pro A2... MSCOND



Terminal row 1

1 (BN)	+3 V	⚠
2 (GN)	RS 485 A	⚠
3 (YE)	RS 485 B	⚠
4 (WH)	GND/shield	⚠
5	+ input	
6	– input	
7	PA	
8	+out 1,2/HART	
9	– out 1/HART	

Terminal row 2

10	hold
11	hold
12	n.c.
13	contr
14	contr
15	n.c.
16	n.c.
17	– out 2
18	n.c.

In addition:


2 HART pins (between terminal row 1 and 2)

⚠ Sensor connection RS-485


Fig.: Terminals, device opened, back of front unit

Wiring Example

Measuring task: Conductivity, temperature
Sensor: Memosens



Connecting a Memosens Sensor



Memosens connection:		Wire color
1	+3 V	Brown
2	RS 485 A	Green
3	RS 485 B	Yellow
4	GND/shield	White, transparent shield

Connect the Memosens sensor to the RS-485 interface of the device using the Memosens cable CA/MS.... . When the sensor is selected in the Configuration menu, the default values are taken as calibration data. They can then be modified by calibration.




NOTICE!


The measuring module slot must be empty!

Stratos Pro A2... MSCOND is intended for connecting a Memosens sensor via RS-485 interface. It does not provide a measuring module.

User Interface, Keypad



Key	Function
meas	<ul style="list-style-type: none">• Return to last menu level• Directly to measuring mode (press > 2 s)• Measuring mode: other display
info	<ul style="list-style-type: none">• Retrieve information• Show error messages
enter	<ul style="list-style-type: none">• Configuration: Confirm entries, next configuration step• Calibration: Continue program flow
menu	<ul style="list-style-type: none">• Measuring mode: Call menu
Arrow keys up / down	<ul style="list-style-type: none">• Menu: Increase/decrease a numeral• Menu: Selection
Arrow keys left / right	<ul style="list-style-type: none">• Previous/next menu group• Number entry: Move between digits




- | | | | |
|----|--|----|---------------------|
| 1 | Temperature | 13 | Info available |
| 2 | Sensocheck | 14 | Hold mode active |
| 3 | Interval/response time | 15 | Main display |
| 4 | Sensor data | 16 | Secondary display |
| 5 | Not used | 17 | Proceed using enter |
| 6 | Limit message:
Limit 1 ▼ or Limit 2 ▲ | 18 | Not used |
| 7 | Alarm | 19 | Diagnostics |
| 8 | Service | 20 | Configuration mode |
| 9 | Parameter set | 21 | Calibration mode |
| 10 | Calibration | 22 | Measuring mode |
| 11 | Memosens | 23 | Sensoface |
| 12 | Waiting time running | 24 | Unit symbols |

Signal Colors (Display Backlighting)

Red	Alarm (in case of fault: display values blink)
Red blinking	Input error: illegal value or wrong passcode
Orange	HOLD mode (Calibration, Configuration, Service)
Turquoise	Diagnostics
Green	Info
Magenta	Sensoface message

Measuring Mode

After the operating voltage has been connected, the analyzer automatically goes to "Measuring" mode. To call the measuring mode from another operating mode (e.g. Diagnostics, Service): Hold **meas** key depressed (> 2 s).



Depending on the configuration, one of the following displays can be set as standard display for the measuring mode (see page 24):

- Measured value, time and temperature (default setting)
- Measured value and selection of parameter set A/B or flow
- Measured value and tag number ("TAG")
- Time and date

Note: By pressing the **meas** key in measuring mode you can view the displays for approx. 60 sec.




You must configure the device for the respective measurement task!

Selecting the Mode / Entering Values


To select the operating mode:

- 1) Hold **meas** key depressed (> 2 s) (directly to measuring mode)
- 2) Press **menu** key: the selection menu appears
- 3) Select operating mode using left / right arrow key
- 4) Press **enter** to confirm the selected mode




To enter a value:

- 5) Select numeral: left / right arrow key
- 6) Change numeral: up / down arrow key
- 7) Confirm entry by pressing **enter**



Display in Measuring Mode



The MAIN DISPLAY is the display which is shown in measuring mode. To call the measuring mode from any other mode, hold the **meas** key depressed for at least 2 sec.


meas key

enter key


meas




meas



enter



approx. 2 s



By pressing **meas** briefly you can step through further displays such as tag number (TAG) or flow (L/h). These displays are turquoise. After 60 sec they switch back to the main display.

Press **enter** to select a display as MAIN DISPLAY – the secondary display shows “MAIN DISPLAY – NO”. Use the **UP** / **DOWN** arrow keys to select “MAIN DISPLAY – YES” and confirm by pressing **enter**. The display color changes to white. This display is now shown in measuring mode.


Color-Coded User Interface

The color-coded user interface guarantees increased operating safety. Operating modes are clearly signaled.


The normal measuring mode is white. Information text appears on a green screen and the diagnostic menu appears on turquoise.

The orange HOLD mode (e.g. during calibration) is quickly visible as is the magenta screen which indicates asset management messages for predictive diagnostics – such as maintenance request, pre-alarm and sensor wear.


The alarm status has a particularly noticeable red display color and is also signaled by flashing display values. Invalid inputs or false pass-codes cause the entire display to blink red so that operating errors are noticeably reduced.




White:
Measuring mode




Red blinking:
Alarm, errors




Orange:
HOLD mode



Magenta:
Maintenance request



Turquoise:
Diagnostics



Green:
Information texts

Operating Modes

Diagnostics

Display of calibration data, display of sensor data, performing a device self-test, viewing the logbook entries, display of hardware/software versions of the individual components. The logbook can store 100 events (00...99). They can be displayed directly on the device. The logbook can be extended to 200 entries using a TAN (Option).

HOLD

Manual activation of HOLD mode, e.g. for servicing. The signal outputs adopt a defined state.

Calibration

Every sensor has typical characteristic values. Calibration is required to supply a correct measured value. The device checks which value the sensor delivers when measuring in a known solution. When there is a deviation, the device can be "adjusted". In that case, the device displays the "actual" value and internally corrects the measurement error of the sensor. During calibration the device is in HOLD mode.

During calibration the device remains in the HOLD mode until it is stopped by the operator.

Configuration


The analyzer must be configured for the respective measurement task. In the "Configuration" mode you select the connected sensor, the measuring range to be transmitted, and the conditions for warning and alarm messages. During configuration the device is in HOLD mode.

Configuration mode is automatically exited 20 minutes after the last keystroke. The device returns to measuring mode.

Service

Maintenance functions (current source), passcode assignment, reset to factory settings, enabling of options (TAN).

Menu Structure of Modes and Functions



HOLD Mode

The HOLD mode is a safety state during configuration and calibration. Output current is frozen (LAST) or set to a fixed value (FIX). Alarm and limit contacts are disabled.

The HOLD mode is indicated by orange display backlighting.


HOLD mode, display icon:



Output signal response

- **LAST:** The output current is frozen at its last value. Recommended for short configuration procedures. The process should not change decisively during configuration. Changes are not noticed with this setting!
- **FIX:** The output current is set to a value that is noticeably different from the process value to signal the control system that the device is being worked at.

Output signal during HOLD:



Terminating the HOLD mode

The HOLD mode is ended by switching to measuring mode (hold **meas** key depressed). The display reads "Good Bye", after that, the HOLD mode is exited.

When the calibration mode is exited, a confirmation prompt ensures that the installation is ready for operation (e.g.: sensor reinstalled, located in process).

External activation of HOLD (SW-A005)

The HOLD mode can be activated from outside by sending a signal to the HOLD input (e.g. from the process control system).



HOLD inactive	0...2 V AC/DC
HOLD active	10...30 V AC/DC

Manual activation of HOLD

The HOLD mode can be activated manually from the HOLD menu. This allows checking or replacing a sensor, for example, without provoking unintended reactions of outputs.

Press **meas** key to return to selection menu.

Alarm

When an error has occurred, **Err xx** is displayed immediately.

Only after expiry of a user-defined delay time will the alarm be registered and entered in the logbook.

During an alarm the display blinks, the display backlighting turns **red**.

Error messages can also be signaled by a 22 mA output current (see Configuration).

2 sec after the failure event is corrected, the alarm status will be deleted.

Alarm and HOLD Messages

Message	Released by	Cause
Alarm (22 mA)	Sensocheck	Polarization
	Error Messages	Flow (CONTROL input)
		ERR 10: Conductance > 3500 mS
HOLD (Last/Fix)	HOLD	HOLD via menu or input
	CONF	Configuration
	CAL	Calibration
	SERVICE	Service

Generating a message via the CONTROL input (min. flow / max. flow)

The CONTROL input can be used for parameter set selection or for flow measurement (pulse principle), depending on its assignment in the "Configuration" menu.

When preset to flow measurement


CONF/CNTR_IN/CONTROL = FLOW

an alarm can be generated when the measured flow exceeds a specified range:

CONF/ALA/FLOW CNTR = ON

CONF/ALA/FLOW min (specify value, default: 5 liters/h)











CONF/ALA/FLOW max (specify value, default: 25 liters/h)



Configuration

Menu Structure of Configuration

The device provides 2 parameter sets “A” and “B”. By switching between the parameter sets you can adapt the device to different measurement situations, for example. Parameter set “B” only permits setting of process-related parameters. The configuration steps are assigned to different menu groups. With the left/right arrow keys you can jump between the individual menu groups. Each menu group contains menu items for setting the parameters. Pressing **enter** opens a menu item. Use the arrow keys to edit a value. Press **enter** to confirm/save the settings. Return to measurement: Hold **meas** key depressed (> 2 s).

Select menu group	Menu group	Code	Display	Select menu item
	Sensor selection	SNS:		
		Menu item 1		
		:		
		Menu item ...		
▶ ↪	Current output 1	OT1:		
▶ ↪	Current output 2	OT2:		
▶ ↪	Compensation	COR:		
▶ ↪	Control input (parameter set or flow measurement)	IN:		
▶ ↪	Alarm mode	ALA:		
▶ ↪	Setting the clock	CLK:		
▶ ↪	Measuring point	TAG:		


Parameter set A/B: configurable menu groups

The device provides 2 parameter sets "A" and "B". By switching between the parameter sets you can adapt the device to different measurement situations, for example. Parameter set "B" only permits setting of process-related parameters.

Menu group	Parameter set A	Parameter set B
SENSOR	Sensor selection	---
OUT1	Current output 1	Current output 1
OUT2	Current output 2	Current output 2
CORRECTION	Compensation	Compensation
CNTR_IN	Control input	---
ALARM	Alarm mode	Alarm mode
PARSET	Parameter set selection	---
CLOCK	Setting the clock	---
TAG	TAG of measuring point	---
GROUP	GROUP of measuring points	---



External switchover of parameter sets A/B

You can switch between parameter sets A and B by applying a signal to the CONTROL input (parameter setting: CNTR-IN – PARSET).



Parameter set A active	0...2 V AC/DC
Parameter set B active	10...30 V AC/DC

Manual Switchover of Parameter Sets A/B

Display	Action	Remark
	To switch between parameter sets: Press meas	Manual selection of parameter sets must have been preset in CONFIG mode. Default setting is a fixed parameter set A. Wrong settings change the measurement properties!
	PARSET blinks in the lower line. Select parameter set using ◀ and ▶ keys.	
	Select PARSET A / PARSET B Confirm by pressing enter Cancel by pressing meas	

Configuration		Choices	Default
SENSOR			
SNS:		MEMOSENS	MEMOSENS
	MEAS MODE	Cond Conc % Sal ‰ USP µS/cm	COND

Configuration			Choices	Default
SENSOR				
SNS:	Cond	MEAS RANGE ¹⁾	x.xxx μ S/cm xx.xx μ S/cm xxx.x μ S/cm xxxx μ S/cm x.xxx mS/cm xx.xx mS/cm xxx.x mS/cm x.xxx S/m xx.xx S/m xx.xx M Ω	xxx.x mS/cm
	Conc	Solution	-01- (NaCl) -02- (HCl) -03- (NaOH) -04- (H2SO4) -05- (HNO3) -06- (H2SO4) -07- (HCl) -08- (HNO3) -09- (H2SO4) -10- (NaOH)	-01- (NaCl)
	TEMP UNIT		°C / °F	°C
	TEMPERATURE (EXT. only with I-input enabled via TAN)		AUTO MAN EXT (only if enabled via TAN)	AUTO
	MAN	TEMPERATURE	-50 ... 250 °C (-58 ... 482 °F)	025.0 °C (077.0 °F)
	CIP COUNT		ON/OFF	0 ... 9999 CYCLES
	SIP COUNT		ON/OFF	0 ... 9999 CYCLES
	CHECK TAG		ON/OFF	OFF
	CHECK GROUP		ON/OFF	OFF

- 1) The range selection allows selecting the maximum resolution. If the upper limit of this range is exceeded, the device automatically switches to the next higher range.

Configuration

Configuration		Choices	Default
Output 1 (OUT1)			
OT1:	CHANNEL		Cond/TMP
	OUTPUT (with Cond only)		LIN / BiLIN / LOG
	LIN	BEGIN (0) 4mA	xxxx
		END 20 mA	xxxx
	BiLIN	BEGIN (0) 4 mA	
		END 20 mA	
		CORNER X	Input range: selected CHANNEL Vertex X: BEGIN ≤ CORNER X ≤ END (rising) BEGIN ≥ CORNER X ≥ END (falling)
		CORNER Y	Input range: selected CHANNEL Default: 12 mA Vertex Y: (0) 4 mA ≤ CORNER Y ≤ 20 mA
	LOG	BEGIN (0) 4mA	Decades
		END 20 mA	Decades
	TMP °C	BEGIN (0) 4mA	–50...250 °C
		END 20 mA	–50...250 °C
	TMP °F	BEGIN (0) 4mA	–58...482 °F
		END 20 mA	–58...482 °F
	FILTERTIME		0...120 SEC
	22mA FAIL		ON/OFF
	22mA FACE		ON/OFF
	HOLD MODE		LAST/FIX
	FIX	HOLD-FIX	(0) 4...22 mA

Configuration			Choices	Default	
Output 2 (OUT2)					
OT2:	CHANNEL		Cond/TMP	TMP	
	... other steps like output 1				
Temperature compensation (CORRECTION)					
COR:	TC SELECT		OFF LIN, NLF, NaCl HCl, NH3, NaOH	OFF	
	LIN	TC LIQUID	00.00 ...19.99%/K	00.00%/K	
		REF TEMP	000.0 ... 199.9 °C	025.0 °C	
	I-INPUT (only with TEMP EXT selected – The I-input option must be enabled via TAN)				
		I-INPUT		0–20 mA / 4–20 mA	4...20 mA
		°C	BEGIN 4 mA	–50...250 °C	000.0 °C
			END 20 mA	–50...250 °C	100.0 °C
		°F	BEGIN 4 mA	–58...482 °F	
	END 20 mA		–58...482 °F		
	Control input (CNTR_IN)				
IN:	CONTROL		Parameter-set switch-over (PARSET) or flow measurement (FLOW)	PARSET	
	FLOW	FLOW ADJUST	12000 pulses/liter	0 ... 20000 pulses/liter	

Monitoring the sensor lines for breakage

The sensor lines are monitored for breakage when the temperature is used for calculating the conductivity or concentration. If the sensor or line is broken, an alarm will be generated (output current FIX or 22 mA, depending on the configuration).

If you want to output a conductivity value that is independent of the measured temperature (uncompensated), you can monitor the sensor lines for breakage by setting “TEMP CHECK” to “ON” in the Alarm menu.

(See following page, ALARM menu)

Configuration

Configuration			Choices	Default
Alarm (ALARM)				
ALA:	DELAYTIME		0...600 SEC	0010 SEC
	SENSOCHECK		ON/OFF	OFF
	TEMP CHECK		ON/OFF	OFF
	FLOW CNTR *)		ON/OFF	OFF
	ON	FLOW MIN **)	005.0 L/h	0 ... 99.9 L/h
		FLOW MAX**)	025.0 L/h	0 ... 99.9 L/h
Parameter set (PARSET)				
PAR:	Select fixed parameter set (A) or switch between A/B via control input or manually in measuring mode		PARSET FIX / CNTR INPUT / MANUAL	PARSET FIX (fixed parameter set A)
Real-time clock (CLOCK)				
CLK:	FORMAT		24 h / 12 h	
	24 h	TIME hh/mm	00..23:00...59	
	12 h	TIME hh/mm	00 ... 12:59 AM / 01 ... 11:59 PM	
	DAY/MONTH		01...31/01...12	
	YEAR		2000...2099	
Measuring points (TAG / GROUP)				
TAG:	(Input in text line)		A...Z, 0...9, – + < > ? / @	
GROUP:	(Input in text line)		0000...9999	0000

* These menu items appear only if selected.

** Hysteresis fixed at 5% of threshold value

Sensor Verification (TAG, GROUP)

Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated, Sensoface gets "sad", and the display backlighting turns purple. The "sad" Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group.

A possibly existing TAG/GROUP will be overwritten.

Configuration (Original for Copy)

Two complete parameter sets are stored in the EEPROM.

As delivered, the two sets are identical but can be edited.

Note:

Fill in your configuration data on the following pages or use them as original for copy.

Configuration (Template for Copy)

Parameter	Parameter set A	Parameter set B
SNS: Sensor type		--- *)
SNS: Measuring mode		---
SNS: Measuring range		---
SNS: Concentration determination		---
SNS: Temperature unit		---
SNS: Temp detection		---
SNS: Manual temp		---
SNS: CIP counter		---
SNS: SIP counter		---
SNS: CHECK TAG		---
SNS: CHECK GROUP		---
OT1: Process variable		
OT1: Lin/bilin/log output		
OT1: Current start		
OT1: Current end		
OT1: Vertex X (bilinear curve only)		
OT1: Vertex Y (bilinear curve only)		
OT1: Filter time		
OT1: FAIL 22 mA (error messages)		
OT1: FACE 22 mA (Sensoface messages)		
OT1: HOLD mode		
OT1: HOLD FIX current		


*) These parameters cannot be adjusted in parameter set B, the values are the same as in parameter set A.

Configuration (Template for Copy)

Parameter	Set A	Set B
OT2: Process variable		
OT2: Lin/bilin/log output		
OT2: Current start		
OT2: Current end		
OT2: Vertex X (bilinear curve only)		
OT2: Vertex Y (bilinear curve only)		
OT2: Filter time		
OT2: FAIL 22 mA (error messages)		
OT2: FACE 22 mA (Sensoface messages)		
OT2: HOLD mode		
OT2: HOLD FIX current		
COR: TC SELECT		
COR: Temp coefficient		
COR: Reference temperature		
COR: Ext. temp input (I input)		
COR: Current range (I input)		
COR: Current start (I input)		
COR: Current end (I input)		
IN: Parameter set A/B or flow		
IN: (Flow meter) Adjusting pulses/liter		
ALA: Delay		
ALA: Sensocheck on/off		
ALA: Tempcheck on/off		
ALA: Flow control FLOW CNTR on/off		
ALA: Minimum flow (hysteresis fixed at 5 %)		
ALA: Maximum flow (hysteresis fixed at 5 %)		
CLK: Time & Date		--- *)
TAG: Measuring point (tag number)		
GROUP: Group of measuring points		





*) These parameters cannot be adjusted in parameter set B, the values are the same as in parameter set A.

Sensor Selecting the parameters



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ , press **enter**.
- 3) Select parameter set using ◀ ▶ keys, press **enter**.
- 4) Select **SENSOR** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "SNS:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.
- 6) Exit: Press **meas** key until the [meas] mode indicator is displayed.


5	Select sensor type	enter
	Select measuring mode	enter
	Select measuring range	enter
	Concentration determination	
	Temperature unit	
	Temperature detection	
	Cleaning cycles	
	Sterilization cycles	
	CHECK TAG	
	CHECK GROUP	

Menu item	Action	Choices
Select sensor type 	Select sensor type using \blacktriangle \blacktriangledown keys. Press enter to confirm.	MEMOSENS 2-ELECTRODE 4-ELECTRODE
Select measuring mode 	Select desired mode using \blacktriangle \blacktriangledown keys. Press enter to confirm.	Cond Conc % Sal ‰ USP μ S/cm
Select measuring range 	For cond measurement only Select desired measuring range using \blacktriangle \blacktriangledown keys. Press enter to confirm.	x.xxx μ S/cm, xx.xx μ S/cm xxx.x μ S/cm, xxxx μ S/cm x.xxx mS/cm, xx.xx mS/cm xxx.x mS/cm , x.xxx S/m xx.xx S/m, xx.xx M Ω
Concentration determination 	For conc measurement only Select desired concentration solution using \blacktriangle \blacktriangledown keys. Press enter to confirm.	-01- (NaCl) -02- (HCl) -03- (NaOH) -04- (H ₂ SO ₄) -05- (HNO ₃) -06- (H ₂ SO ₄) -07- (HCl) -08- (HNO ₃) -09- (H ₂ SO ₄) -10- (NaOH)

Configuration




Sensor

Select: Temperature unit, temperature detection




- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **SENSOR** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "SNS:" code.
Press **enter** to select menu,
edit using arrow keys (see next page).
Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

Select sensor type	5	enter
Select measuring mode		↺
Select range		↺
Concentration determination		
Temperature unit		
Temperature detection		
Cleaning cycles		
Sterilization cycles		
CHECK TAG		
CHECK GROUP		

Menu item	Action	Choices
Temperature unit 	Select °C or °F using ▲ ▼ keys. Press enter to confirm.	°C / °F
Temperature detection 	Select mode using ▲ ▼ keys: AUTO: Measured by sensor MAN: Direct input of temperature, no measurement (see next step) EXT: Temperature specified via current input (only if TAN E enabled) Press enter to confirm.	AUTO MAN EXT
(Manual temperature) 	Modify digit using ▲ ▼ keys, select next digit using ◀ ▶ keys. Press enter to confirm.	–50...250 °C (–58...482 °F)



Sensor

Adjust: Cleaning cycles, sterilization cycles



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **SENSOR** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "SNS:" code.
Press **enter** to select menu,
edit using arrow keys (see next page).
Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

Select sensor type	5	enter
Select measuring mode		enter
Select range		enter
Concentration determination		
Temperature unit		
Temperature detection		
Cleaning cycles		
Sterilization cycles		
CHECK TAG		
CHECK GROUP		

Menu item	Action	Choices
CIP / SIP		
Cleaning cycles on/off 	Select ON or OFF using ▲ ▼ keys. Activates/deactivates log- ging in extended logbook Press enter to confirm.	ON/OFF
Sterilization cycles on/off 	Select ON or OFF using ▲ ▼ keys. Activates/deactivates log- ging in extended logbook Press enter to confirm.	ON/OFF


The cleaning and sterilization cycles are logged to measure the load on the sensor.

Note:

A CIP or SIP cycle is only entered into the logbook 2 hours after the start to ensure that the cycle is complete.



With Memosens sensors, an entry is also made in the sensor.

Memosens Sensor Sensor Verification (TAG, GROUP)



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ , press **enter**.
- 3) Select parameter set using ◀ ▶ keys, press **enter**.
- 4) Select **SENSOR** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "SNS:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.
- 6) Exit: Press **meas** key until the [meas] mode indicator is displayed.

	5
Select sensor type	enter
Select measuring mode	enter
Select range	enter
Concentration determination	
Temperature unit	
Temperature detection	
Cleaning cycles	
Sterilization cycles	
CHECK TAG	
CHECK GROUP	

Menu item	Action	Choices
TAG 	Select ON or OFF using ▲ ▼ keys. Press enter to confirm. When switched on, the entry for "TAG" in the Memosens sensor is com- pared to the entry in the analyzer. If the entries differ, a mes- sage will be generated.	ON/OFF
GROUP 	Select ON or OFF using ▲ ▼ keys. Press enter to confirm. Function as described above	ON/OFF


Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated, Sensoface gets "sad", and the display backlighting turns purple. The "sad" Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group. A possibly existing TAG/GROUP will be overwritten.





Current Output 1

Output current range. Process variable.




- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **OUT1** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "OT1:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

5	Process variable	enter
	LIN/biLIN/LOG output	enter
	Current start	
	Current end	
	Time averaging filter	
	Output current during error message	
	Output current during Sensoface messages	
	Output current during HOLD	
	Output current for HOLD FIX	

Menu item	Action	Choices
Process variable 	Select using \blacktriangle \blacktriangledown keys: Cond: Conductivity TMP: Temperature Press enter to confirm. Then select characteristic (LIN/biLIN/LOG).	Cond/TMP 
Current start 	Modify digit using \blacktriangle \blacktriangledown keys, select next digit using \blacktriangleleft \blacktriangleright keys. Press enter to confirm.	Entered value applies to selected process variable/ range If the adjusted range is exceeded, the device automatically switches to the next higher range (Autorange)
Current end 	Enter value using \blacktriangle \blacktriangledown \blacktriangleleft \blacktriangleright keys. Press enter to confirm.	Entered value applies to selected process variable/ range If the adjusted range is exceeded, the device automatically switches to the next higher range (Autorange)


Assignment of measured values: Current start and current end

Example 1: Range 0...200 mS/cm




Example 2: Range 100...200 mS/cm

Advantage: Higher resolution in range of interest






Current Output 1

Output current curve, bilinear



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **OUT1** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "OT1:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.


	5
Process variable	
LIN/biLIN/LOG output	enter
Current start	
Current end	
Bilinear: Vertex X	
Bilinear: Vertex Y	
Time averaging filter	
Output current during error message	
Output current during Sensoface messages	
Output current during HOLD	
Output current for HOLD FIX	

Menu item	Action	Choices
Output current curve 	Select using ▲ ▼ keys. Press enter to confirm.	LIN Linear characteristic biLIN Bilinear curve LOG Logarithmic curve
Current start and current end 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	Entered value applies to selected process variable/range If the adjusted range is exceeded, the device automatically switches to the next higher range (Autorange)
Bilinear curve: Vertex X/Y 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	Entered value applies to selected vertex of bilinear curve "Corner X" (process variable) and "Corner Y" (output current) – see figure below.

Vertex of bilinear curve

Output current

[mA]



Example:

Current range 4 ... 20 mA,

Current start: 0 µS/cm

Current end: 200 µS/cm

Vertex:

"CORNER X": 10 µS/cm (process variable)

"CORNER Y": 12 mA (output current)

Result: The output current change in the range 0 ... 10 µS/cm is much greater than in the range 10 ... 200 µS/cm.

Process variable
[µS/cm]

Logarithmic Curve

Nonlinear output current characteristic: allows measurements over several decades, e.g. measuring very low values with a high resolution and high values with a low resolution.

Parameters required: Start and end value

Possible start and end values

The start value must be at least one decade lower than the end value.

Start value and end value must be specified in the same units
(either in $\mu\text{S}/\text{cm}$ or in S/m , see listing):

1.0 $\mu\text{S}/\text{cm}$	
10.0 $\mu\text{S}/\text{cm}$	0.001 S/m
100.0 $\mu\text{S}/\text{cm}$	0.01 S/m
1.0 mS/cm	0.1 S/m
10.0 mS/cm	1.0 S/m
100.0 mS/cm	10.0 S/m
1000 mS/cm	100 S/m

The start value

is the next decade value below the lowest measured value.

The end value


is the next decade value above the highest measured value.




The number of decades results from:

$$\text{Number of decades} = \log(\text{end value}) - \log(\text{start value})$$

The output current value is defined as follows:

$$\text{Output current} = 16 \text{ mA} * \frac{\log(\text{measured value}) - \log(\text{start value})}{\text{Number of decades}} + 4 \text{ mA}$$



Menu item	Action	Choices
Logarithmic curve of output current 	Select using ▲ ▼ keys. Press enter to confirm.	LOG Logarithmic curve biLIN Bilinear curve LIN Linear characteristic
Start value 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	Start value of logarithmic output curve
End value 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	End value of logarithmic output curve

Possible start and end values for the logarithmic curve

S/cm:

1.0 μ S/cm, 10.0 μ S/cm, 100.0 μ S/cm,


1.0 mS/cm, 10.0 mS/cm, 100.0 mS/cm, 1000 mS/cm

S/m:

0.001 S/m, 0.01 S/m, 0.1 S/m, 1.0 S/m, 10.0 S/m, 100 S/m


Current Output 1

Adjusting the time interval of the output filter



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **OUT1** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "OT1:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

	5
Process variable	enter
LIN/biLIN/LOG output	enter
Current start	
Current end	
Time averaging filter	
Output current during error message	
Output current during Sensoface messages	
Output current during HOLD	
Output current for HOLD FIX	

Menu item	Action	Choices
Time averaging filter 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	0...120 SEC (0000 SEC)


Time averaging filter

To smoothen the current output, a low-pass filter with adjustable filter time constant can be switched on. When there is a jump at the input (100 %), the output level is at 63 % after the time interval has been reached. The time interval can be set from 0 to 120 sec. If the time interval is set to 0 sec, the current output directly follows the input.

Note:


The filter only acts on the current output, not on the display or the limit value!

During HOLD the filter is not applied. This prevents a jump at the output.






Current Output 1

Output current during Error and HOLD




- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **OUT1** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "OT1:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

Process variable	5	enter
LIN/biLIN/LOG output		
Current start		
Current end		
Time averaging filter		
Output current during error message		
Output current during Sensoface messages		
Output current during HOLD		
Output current for HOLD FIX		


Menu item	Action	Choices
Output current during error message 	Select ON or OFF using \blacktriangle \blacktriangledown keys. Press enter to confirm.	ON/OFF
Output current during Sensoface messages OT1: FACE 22 mA	Select ON or OFF using \blacktriangle \blacktriangledown keys. Confirm by pressing enter	ON/OFF
Output current during HOLD 	LAST: During HOLD the last measured value is maintained at the output. FIX: During HOLD a value (to be entered) is maintained at the output. Select using \blacktriangle \blacktriangledown keys Press enter to confirm.	LAST/FIX
Output current for HOLD FIX 	Only with FIX selected: Enter current which is to flow at the output during HOLD Enter value using \blacktriangle \blacktriangledown \blacktriangleleft \blacktriangleright keys Press enter to confirm.	04.00...22.00 mA (21.00 mA)

Output signal during HOLD:




Current Output 2

Output current range. Process variable ...






- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **OUT2** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "OT2:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

Process variable	5	enter
LIN/biLIN/LOG output		
Current start		
Current end		
Bilinear: Vertex X		
Bilinear: Vertex Y		
Time averaging filter		
Output current during error message		
Output current during Sensoface messages		
Output current during HOLD		
Output current for HOLD FIX		

Menu item	Action	Choices
Process variable 	Select using ▲ ▼ keys: Cond: Conductivity TMP: Temperature Press enter to confirm.	Cond/ TMP Begin: 0 °C End: 100°C
<ul style="list-style-type: none"> • • • 		

All the following adjustments are made as for current output 1 (see there)!







Temperature Compensation Selecting the compensation method



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **CORRECTION** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "COR:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.


5

Temperature compensation	enter
Temperature compensation, process medium	↩
Enter reference temperature	↩
Current input, external temp measurement	
Current start	
Current end	

Menu item	Action	Choices
Temperature compensation	Select desired compensation using ▲ ▼ keys:	
	OFF: Temperature compensation switched off	
	LIN: Linear temperature compensation with entry of temperature coefficient	
	nLF: Temperature compensation for natural waters to EN 27888	
	NaCl: Temperature compensation for ultrapure water with NaCl traces	
	HCl: Temperature compensation for ultrapure water with HCl traces	
	NH3: Temperature compensation for ultrapure water with NH ₃ traces Press enter to confirm.	
	NaOH (without figure)	






Temperature Compensation

TC process medium. Current input for temp measurement.




- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **CORRECTION** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "COR:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

5	Temperature compensation	enter
	Temperature compensation, process medium	enter
	Enter reference temperature	enter
	Current input, external temp measurement (if enabled via TAN)	
	Current start	
	Current end	


Menu item	Action	Choices
Temperature compensation, process medium 	With linear compensation only: Step 1: Enter temperature compensation of the process medium. Step 2: Enter reference temperature Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	00.00...19.99 %/K
Enter reference temperature 		
With external temp measurement (current input enabled / TAN):		
Current range 	Select desired range using ▲ ▼ keys. Press enter to confirm.	4-20 mA / 0-20 mA
Current start 	Modify digit using ▲ ▼ keys, select next digit using ◀ ▶ keys. Press enter to confirm.	Input range: -50...250 °C / -58...482 °F
Current end 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	Input range: -50...250 °C / -58...482 °F




CONTROL Input

Parameter set selection via external signal or flow measurement



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **CNTR_IN** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "IN:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.



Menu item	Action	Choices
Select function of CONTROL input 	Select using ▲ ▼ keys. Press enter to confirm.	PARSET (selecting parameter set A/B via signal at CONTROL input)
		Flow (for connecting a pulse-output flow meter)
Adjust to flow meter: 	With “Flow” selected, you must adjust the device to the flow meter used. Enter value using arrow keys. Press enter to confirm.	12000 pulses/liter

In the alarm menu you can configure flow monitoring. When you have set CONTROL to FLOW, you can specify 2 additional limit values for maximum and minimum flow.

If the measured value lies outside this range, an alarm message and a 22-mA error signal (if configured) will be generated.

Display

Flow measurement in measuring mode




Display

Flow measurement (sensor monitor)





Alarm Settings

Delay. Sensocheck. Tempcheck.



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **ALARM** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "ALA:" code.
Press **enter** to select menu,
edit using arrow keys (see next page).
Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

5	ALA: Delay	enter
	Alarm: Sensocheck	
	Alarm: Tempcheck	
	Alarm: CONTROL input	
	For flow monitoring: Max. flow alarm	
	For flow monitoring: Min. flow alarm	


Menu item	Action	Choices
Delay 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	0...600 SEC (010 SEC)
Sensocheck 	Select Sensocheck (continuous monitoring of sensor). Select ON or OFF using ▲ ▼ keys. Press enter to confirm (At the same time, Sensoface is activated. With OFF, Sensoface is also switched off.)	ON/OFF
Tempcheck (see page 37)	To monitor the tempera- ture probe with TC OFF selected: Select Tempcheck ON using ▲ ▼ keys. Press enter to confirm. Now, the temperature probe will be monitored.	ON/OFF

Error messages can be signaled by a 22 mA output current (see Error Messages and Configuration of Output 1/Output 2).

The alarm delay time delays the color change of the display back-lighting to red and the 22 mA signal (if configured).


Alarm Settings

CONTROL input (FLOW MIN, FLOW MAX)






- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶ keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- 4) Select **ALARM** menu using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "ALA:" code.
Press **enter** to select menu,
edit using arrow keys (see next page).
Confirm (and proceed) using **enter**.
- 6) End: Press **meas** key until the [meas] mode indicator is displayed.

ALARM: Delay	5	enter
Alarm: Sensocheck		
Alarm: Tempcheck		
Alarm: CONTROL input		
For flow monitoring: Max. flow alarm		
For flow monitoring: Min. flow alarm		

Menu item	Action	Choices
CONTROL input 	The CONTROL input can generate an alarm when assigned to FLOW (flow monitoring) in the CONF menu: FLOW CNTR Flow measurement: allows monitoring the minimum and maximum flow (pulse counter)	ON/OFF (FLOW MIN, FLOW MAX.)
Alarm Minimum flow FLOW MIN	Specify value	Default: 05.00 liters/h
Alarm Maximum flow FLOW MIN	Specify value	Default: 25.00 liters/h

Time and Date Measuring Points (TAG/GROUP)



- 1) Press **menu** key.
- 2) Select **CONF** using ◀ ▶, press **enter**.
- 3) Select parameter set A using ◀ ▶ keys, press **enter**.
- 4) Select **CLOCK** or **TAG** using ◀ ▶ keys, press **enter**.
- 5) All items of this menu group are indicated by the "CLK:" or "TAG" code. Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.
- 6) Exit: Press **meas** key until the [meas] mode indicator is displayed.

5

Time format	enter
Time	↻
Day and month	↻
Year	
TAG of measuring point	
GROUP of measuring points	

Time and Date

Control of the calibration and cleaning cycles is based on the time and date of the integrated real-time clock.

In measuring mode the time is shown in the lower display. When using digital sensors, the calibration data is written in the sensor head. In addition, the logbook entries (cf Diagnostics) are provided with a time stamp.


Note:

There is no automatic switchover from winter to summer time!
Be sure to manually adjust the time!

Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated, Sensoface gets “sad”, and the display backlighting turns purple. The “sad” Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group. A possibly existing TAG/GROUP will be overwritten.

Menu item	Action	Choices
<p>Measuring point (TAG)</p> 	<p>In the lower display line you can enter a designation for the measuring point (TAG) and for a group of measuring points (GROUP) if applicable. Up to 32 digits are possible. By pressing meas (repeatedly) in the measuring mode you can view the tag number. Select character using ▲ ▼ keys, select next digit using ◀ ▶ keys. Press enter to confirm.</p>	<p>A...Z, 0...9, – + < > ? / @</p> <p>The first 10 characters are seen in the display without scrolling.</p>

Digital Sensors


Operation

Stratos Pro can be operated with digital Memosens sensors.


The sensor type is selected during **Configuration**.

The device only switches to measuring mode when the connected sensor corresponds to the type configured (Sensoface is friendly).





The Memosens logo appears on the screen.



Otherwise, an error message is released. The **info** icon is displayed. You can display the error text in the bottom line using the ◀ ▶ keys. Sensoface is sad (see table of error messages and Sensoface in the Appendix):





Connecting a Digital Sensor

Step	Action/Display	Remark
Connect sensor		Before a digital sensor is connected, the error message "No sensor" is displayed.
Wait until the sensor data are displayed.		The hourglass in the display blinks.
Check sensor data	 <p>View sensor information using ◀ ▶ keys, press enter to confirm.</p>	<p>Display color changes to green.</p> <p>Sensoface is friendly when the sensor data are okay.</p>
Go to measuring mode	Press meas , info or enter	After 60 sec the device automatically returns to measuring mode (time-out).
Possible error messages		
Sensor defective. Replace sensor		When this error message appears, the sensor cannot be used. Sensoface is sad.

Replacing a Sensor

A digital sensor should only be replaced during HOLD mode to prevent unintended reactions of the outputs or contacts. When you first want to calibrate the new sensor, it can also be replaced in calibration mode.

Step	Action/Display	Remark
Select HOLD mode	Press menu key to call the selection menu, select HOLD using the ◀ ▶ keys, press enter to confirm.	Now the device is in HOLD mode. The HOLD mode can also be activated externally via the HOLD input. During HOLD the output current is frozen at its last value or set to a fixed value.
Disconnect and remove old sensor		
Install and connect new sensor.		Temporary messages which are activated during the replacement are indicated but not output to the alarm contact and not entered in the log-book.
Wait until the sensor data are displayed.		

Step	Action/Display	Remark
Check sensor data	 <p>View sensor information using ◀ ▶ keys, press enter to confirm.</p>	You can view the sensor type, serial number, and last calibration date.
Check measured values		
Exit HOLD	<p>Hit meas key: Return to selection menu.</p> <p>Hold meas key depressed: Device switches to measuring mode</p>	The sensor replacement is entered in the extended logbook.

Calibration

Note:

- All calibration procedures must be performed by trained personnel. Incorrectly set parameters may go unnoticed, but change the measuring properties.

Calibration can be performed by:

- determining the cell constant with a known calibration solution
- input of cell constant (e.g., for ultrapure-water sensors)
- sampling (product calibration)
- temperature probe adjustment

The calibration data of a Memosens sensor is stored in the sensor. Therefore, it can be pre-calibrated externally (e.g., using the Portavo 907/908 portable analyzer or the “MemoSuite” software).

Selecting a Calibration Mode





Calibration adapts the device to the individual sensor characteristics. Access to calibration can be protected with a passcode (SERVICE menu).

First, you open the calibration menu and select the calibration mode:



CAL_SOL	Calibration with calibration solution
CAL_CELL	Calibration by entry of cell constant
P_CAL	Product calibration (calibration with sampling)
CAL_RTD	Temperature probe adjustment

Calibration with Calibration Solution

Input of temperature-corrected value of calibration solution with simultaneous display of cell constant

Display	Action	Remark
	Select Calibration. Press enter to proceed. Select CAL_SOL calibration method. Press enter to proceed.	
	Ready for calibration. Hourglass blinks.	Display (3 sec) Now the device is in HOLD mode.
	Immerse sensor in calibration solution. Enter the temperature- corrected value of the calibration solution using the arrow keys (see table). Press enter to confirm.	Lower line: Display of cell constant and temperature
	The determined cell constant is displayed. The "hourglass" icon is blinking. Press enter to proceed.	

Calibration with Calibration Solution






Display	Action	Remark
	<p>Display of selected process variable (here: mS/cm). Now the device is in HOLD mode: Reinstall the sensor and check whether the measurement is OK. MEAS ends calibration, REPEAT permits repetition.</p>	
	<p>With MEAS selected: End calibration by pressing enter.</p>	<p>Display of conductivity and temperature, Sensoface is active. After end of calibration, the outputs remain in HOLD mode for a short time. After display of GOOD BYE, the device automatically returns to measuring mode.</p>

Note:

- Be sure to use known calibration solutions and the respective temperature-corrected conductivity values (see table on calibration solution).
- During the calibration procedure the temperature must be kept constant.

Calibration by Entry of Cell Constant

You can directly enter the value for the cell constant of a sensor. This value must be known, e.g. determined beforehand in the laboratory. The selected process variable and the temperature are displayed.

Display	Action	Remark
	Select Calibration. Press enter to proceed. Select CAL_CELL calibration method. Press enter to proceed.	
	Ready for calibration. Hourglass blinks.	Display (3 sec) Now the device is in HOLD mode.
	Enter cell constant. Press enter to proceed.	The selected process variable and the temperature are displayed.
	The device shows the calculated cell constant (at 25 °C). Sensoface is active.	
	Use the arrow keys to select: <ul style="list-style-type: none"> • MEAS (end) • REPEAT Press enter to proceed.	End: HOLD is deactivated after a short time.

Product Calibration




Calibration by sampling – for product calibration, the uncompensated conductivity ($\mu\text{S/cm}$, mS/cm , S/m) is used.

During product calibration the sensor remains in the process.






The measurement process is only interrupted briefly.

Procedure:






- 1) The sample is measured in the lab or directly on the site using a portable meter. To ensure an exact calibration, the sample temperature should correspond to the measured process temperature.
During sampling the device saves the currently measured value and then returns to measuring mode. Then, the “calibration” mode indicator blinks.
- 2) In the second step you enter the measured sample value in the device. From the difference between the stored measured value and entered sample value, the device calculates the new cell constant.
If the sample is invalid, you can take over the value stored during sampling. In that case the old calibration values are stored.
Afterwards, you can start a new product calibration.

Display	Action	Remark
	Select Calibration. Press enter to proceed. Select P_CAL calibration method. Press enter to proceed.	
	Ready for calibration. Hourglass blinks.	Display (3 sec) Now the device is in HOLD mode.
	Take sample and save value. Press enter to proceed.	Now the sample can be measured in the lab.





Product Calibration

Display	Action	Remark
	The device returns to measuring mode.	From the blinking CAL mode indicator you see that product calibration has not been terminated.
	Product calibration step 2: When the sample value has been determined, open the product calibration once more	Display (3 sec) Now the device is in HOLD mode.
	The stored value is displayed (blinking) and can be overwritten with the lab value. Press enter to proceed.	
	Display of new cell constant (based on 25°C). Sensoface is active. To end calibration: Select MEAS, then enter	To repeat calibration: Select REPEAT, then enter
	After calibration is ended, the device will switch to measuring mode.	After end of calibration, the outputs remain in HOLD mode for a short time.

Temp Probe Adjustment

Display	Action	Remark
	Select Calibration. Press enter to proceed. Select CAL_RTD calibration method. Press enter to proceed.	Wrong settings change the measurement properties!
	Measure the tempera- ture of the process medium using an external thermometer.	Display (3 sec) Now the device is in HOLD mode.
	Enter the measured temperature value. Maximum difference: 10 K. Press enter to proceed.	Display of actual temperature (un- compensated) in the lower display.
	The corrected tempera- ture value is displayed. Sensoface is active. To end calibration: Select MEAS, then enter To repeat calibration: Select REPEAT, then enter	After end of calibra- tion, the outputs re- main in HOLD mode for a short time.
	After calibration is ended, the device will switch to measuring mode.	

Measurement

Display	Remark
 <p>or AM/PM and °F:</p> 	<p>From the configuration or calibration menus, you can switch the device to measuring mode by pressing the meas key.</p> <p>In the measuring mode the upper display line shows the configured process variable (Cond or temperature), the lower display line shows the time and the second configured process variable (Cond or temperature). The [meas] mode indicator lights and the active parameter set (A/B) is indicated. A/B is not displayed with parameter set Fix A.</p>
<p>By pressing the meas key you can step through the following displays. When no key has been pressed for 60 sec, the device returns to the standard display.</p>	
 	<p>1) Selecting the parameter set (if set to “manual” in the configuration). Select the desired parameter set using the ◀ ▶ arrow keys (PARSET A or PARSET B blinks in the lower display line). Press enter to confirm.</p> <p>Further displays (each by pressing meas).</p> <p>2) Display of measuring point (“TAG”)</p> <p>3) Display of time and date</p> <p>4) Display of output current(s)</p>

Diagnostics


In the Diagnostics mode you can access the following menus without interrupting the measurement:

CALDATA	viewing the calibration data
SENSOR	viewing the sensor data
SELFTEST	starting a device self-test
LOGBOOK	viewing the logbook entries (if activated)
MONITOR	displaying currently measured values
VERSION	displaying device type, software version, serial number


Access to diagnostics can be protected with a passcode (SERVICE menu).

Please note:

HOLD is not active during Diagnostics mode!


Action	Key	Remark
Activate Diagnostics		Press menu key to call the selection menu. (Display color changes to turquoise.) Select DIAG using ◀ ▶ keys, press enter to confirm.
Select diagnostics option		Use ◀ ▶ keys to select from: CALDATA SENSOR SELFTEST LOGBOOK MONITOR VERSION See next pages for further proceeding.
Exit	meas	Exit by pressing meas .

Diagnostics

Display	Menu item
	<p>Displaying the calibration data</p> <p>Select CALDATA using ◀ ▶ , press enter to confirm. Use the ◀ ▶ keys to select the desired parameter from the bottom line of the display (LAST_CAL CELLFACTOR ZERO). The selected parameter is shown in the main display.</p> <p>Press meas to return to measurement.</p>

Display

Menu item










Device self-test

(To abort, you can press **meas.**)

- 1) **Display test:** Display of all segments with changing background colors white/green/red. Press **enter** to proceed.
- 2) **RAM test:** Hourglass blinks, then display of --PASS-- or --FAIL--
Press **enter** to proceed.
- 3) **EEPROM test:** Hourglass blinks, then display of --PASS-- or --FAIL--
Press **enter** to proceed.
- 4) **FLASH test:** Hourglass blinks, then display of --PASS-- or --FAIL--
Press **enter** to proceed.

Diagnostics

Display	Menu item
	Displaying the logbook entries (if the option has been enabled) Select LOGBOOK using ◀ ▶, press enter to confirm. With the ▲ ▼ keys, you can scroll backwards and forwards through the logbook (entries -00-...-99-), -00- being the last entry. If the display is set to date/time, you can search for a particular date using the ▲ ▼ keys. Press ◀ ▶ to view the corresponding message text. If the display is set to the message text, you can search for a particular message using the ▲ ▼ keys. Press ◀ ▶ to display the date and time. Press meas to return to measurement.
	
	
	Extended logbook / Audit Trail (via TAN) With the ▲ ▼ keys, you can scroll backwards and forwards through the extended logbook (entries -000-...-99-), -000- being the last entry. Display: CFR Audit Trail also records function activations (CAL CONFIG SERVICE), some Sensoface messages, and opening of the enclosure.
	Displaying the currently measured values (sensor monitor): Select MONITOR using ◀ ▶, press enter to confirm. Use the ◀ ▶ keys to select the desired parameter from the bottom line of the display (R_COND G_COND RTD TEMP I-INPUT (Option) OPERATION TIME CIP SIP). The selected parameter is shown in the upper display line. Press meas to return to measurement.
Display example: 	

Display	Menu item
 The image shows a monochrome LCD screen. At the top, it displays '1.0.2' in large digits, followed by 'SW' to its right. Below this, it shows 'SERIAL-No 0073' in a smaller font. At the bottom center, there is a small rectangular button labeled 'diag'. To the right of the 'diag' button, there is a small square icon containing a right-pointing arrow.	<p>Version</p> <p>Here, you find the data you require for requesting a device-specific option.</p> <p>Display of device type, software/hardware version, and serial number for all device components, and bootloader version (e.g., 1.0.6 BTL).</p> <p>Use the ▲ ▼ keys to switch between software and hardware version. Press enter to proceed to next device component.</p>




Service



In the Service mode you can access the following menus:




MONITOR	Displaying currently measured values
OUT1	Testing current output 1
OUT2	Testing current output 2 (only when equipped with 2nd current output)
CODES	Assigning and editing passcodes
DEFAULT	Resetting the device to factory settings
OPTION	Enabling options via TAN

Note:

HOLD is active during Service mode!

Action	Key/Display	Remark
Activate Service		Press menu key to call the selection menu. Select SERVICE using ◀ ▶ keys, press enter to confirm.
Passcode		Enter passcode "5555" for service mode using the ▲ ▼ ◀ ▶ keys. Press enter to confirm.
Display		In service mode the following icons are displayed: <ul style="list-style-type: none">• [diag] mode indicator• HOLD triangle• Service (wrench)
Exit	meas	Exit by pressing meas .

Display	Menu item
	<p>Displaying currently measured values (sensor monitor) with HOLD mode activated: Select MONITOR using ◀ ▶, press enter to confirm. Select variable in the bottom text line using ◀ ▶.</p> <p>The selected parameter is shown in the upper display line.</p> <p>As the device is in HOLD mode, you can perform validations using simulators without influencing the signal outputs.</p> <p>Return to Service menu: Hold meas depressed for longer than 2 sec. Press meas once more to return to measurement.</p>
	<p>Specifying the current for outputs 1 and 2: Select OUT1 or OUT2 using the ◀ ▶ keys, press enter to confirm. Enter a valid current value for the respective output using ▲ ▼ ◀ ▶ keys. Confirm by pressing enter. For checking purposes, the actual output current is shown in the bottom right corner of the display. Exit by pressing enter or meas. OUT2: Only when equipped with 2nd current output</p>

Display	Menu item
	<p>Assigning passcodes: In the “SERVICE - CODES” menu you can assign passcodes to DIAG, HOLD, CAL, CONF, and SERVICE modes (Service preset to 5555).</p> <p>When you have lost the Service passcode, you have to request an “Ambulance TAN” from the manufacturer specifying the serial number of your device. To enter the “Ambulance TAN”, call the Service function and enter passcode 7321. After correct input of the ambulance TAN the device signals “PASS” for 4 sec and resets the Service passcode to 5555.</p>
	<p>Reset to factory settings: In the “SERVICE - DEFAULT” menu you can reset the device to factory settings.</p> <p>NOTICE! After a reset to factory setting the device must be reconfigured completely, including the sensor parameters!</p>
	<p>Option request: Communicate the serial number and hardware/software version of your device to the manufacturer. These data can be viewed in the Diagnostics/Version menu.</p> <p>The “transaction number” (TAN) you will then receive is only valid for the device with the corresponding serial number.</p> <p>Release of options: Options come with a “transaction number” (TAN). This TAN must be entered and confirmed using enter to release the option.</p>

According to the “USP” directive (U.S.Pharmacopeia), Section 645 “Water Conductivity” the conductivity of pharmaceutical waters can be monitored online. To do so, the conductivity is measured without temperature compensation and is compared with limit values (see table on next page).

The water is usable when the conductivity is below the USP limit. If the conductivity values are higher, further test steps must be performed according to the directive.

Configuring:

- **SNS** menu group:

































When “USP function” has been selected, the measuring range is fixed to 00.00.....99.99 $\mu\text{S/cm}$. Temperature compensation is switched off. Temperature is monitored.




If the USP limit is exceeded, a 22 mA signal is output.

Temperature/Conductivity Table as per USP

Temp (°C)	Cond ($\mu\text{S/cm}$)	Temp (°C)	Cond ($\mu\text{S/cm}$)
0	0.6	55	2.1
5	0.8	60	2.2
10	0.9	65	2.4
15	1.0	70	2.5
20	1.1	75	2.7
25	1.3	80	2.7
30	1.4	85	2.7
35	1.5	90	2.7
40	1.7	95	2.9
45	1.8	100	3.1
50	1.9		

Operating States

Operating status	OUT 1	OUT 2	Time out
Measuring			-
DIAG			60 s
CAL_SOL Calibration solution			No
CAL_CELL Cell constant			No
P_CAL Product cal S1			No
P_CAL Product cal S2			No
CAL_RTD Temp adjustment			No
CONF ParSet A			20 min
CONF ParSet B			20 min
SERVICE MONITOR			20 min
SERVICE OUT 1			20 min
SERVICE OUT 2			20 min
SERVICE CODES			20 min
SERVICE DEFAULT			20 min
SERVICE OPTION			20 min
HOLD input			No

Explanation:  as configured (Last/Fix or Last/Off)
 active  manual

A2...X: Supply Units and Connection

Recommended Power Supply Units: Order No.:

Repeater power supply, Ex, 90...253 V AC, WG 21 A7
output 4...20 mA

Repeater power supply, Ex, 90...253 V AC, WG 21 A7 Opt. 470
HART, output 4...20 mA


Repeater power supply, Ex, 24 V AC/DC, WG 21 A7 Opt. 336
output 4...20 mA

Repeater power supply, Ex, 24 V AC/DC, WG 21 A7 Opt. 336, 470
HART, output 4...20 mA

Repeater power supply, non-Ex, 24 V DC, IsoAmp PWR B 10116
output 4...20 mA

Repeater power supply, non-Ex, 24 V DC, IsoAmp PWR A 20100
HART, output 0/4...20 mA / 0...10 V

Connection to Supply Units



Product Line and Accessories

Order Code Stratos Pro A 2...

Example	A	2	0	1	X	-	MSCONDI	-	1	TAN
2-wire / 4-20 mA	A	2								B,C,E
Communication										
Without (HART retrofittable via TAN)			0							A
Version number										
Version				1						
Approvals										
General Safety					N					
ATEX / IECEx Zone 2					B					
ATEX / IECEx / FM / CSA Zone 1 / CI 1 Div 1					X					
Measuring channel										
Memosens pH / Redox	digital						MSPH			G
Memosens Cond	digital						MSCOND			
Memosens CondI	digital						MSCONDI			
Memosens Oxy	digital						MSOXY			
Dual COND (2x2-electrode sensors, analog)				N			CC			
pH / ORP value	Measuring module						PH			F, G
(ISM digital per TAN)										
Cond, 2-/4-electrode	Measuring module						COND			
Conductivity, electrodeless	Measuring module						CONDI			
Oxygen (ISM digital and traces per TAN)	Measuring module						OXY			D, F
Options										
Without 2nd current output									0	
With 2nd current output									1	
TAN options										
HART							SW-A001			(A)
Logbook							SW-A002			(B)
Extended logbook (Audit Trail)							SW-A003			(C)
Trace oxygen measurement							SW-A004			(D)
Current input + 2 digital inputs							SW-A005			(E)
ISM digital							SW-A006			(F)
Pfautler							SW-A007			(G)
Mounting accessories										
Pipe-mount kit							ZU 0274			
Protective hood							ZU 0737			
Panel-mount kit							ZU 0738			

COND input	Input for Memosens sensors 0.2 $\mu\text{S} \cdot \text{cm} \dots 1000 \text{ mS} \cdot \text{cm}$ (Conductance limited to 3500 mS)		
Measuring ranges	Conductivity	0.000 ... 9.999 $\mu\text{S}/\text{cm}$	
		00.00 ... 99.99 $\mu\text{S}/\text{cm}$	
		000.0 ... 999.9 $\mu\text{S}/\text{cm}$	
		0000 ... 9999 $\mu\text{S}/\text{cm}$	
		0.000 ... 9.999 mS/cm	
		00.00 ... 99.99 mS/cm	
		000.0 ... 999.9 mS/cm	
		0.000 ... 9.999 S/cm	
		00.00 ... 99.99 S/cm	
	Resistivity	00.00 ... 99.99 $\text{M}\Omega \cdot \text{cm}$	
	Concentration	0.00 ... 9.99 %	
	Temperature	-20.0 ... +150.0 °C (-4.0 ... +302.0 °F)	
	Salinity	0.0 ... 45.0 ‰ (0 ... 35 °C / +32 ... +95 °F)	
	Response time (T90)	Approx. 1 s	
Measurement error^{1,2,3)}	Depending on Memosens		
Temp compensation *	(OFF)	Without	
	(LIN)	Linear characteristic 00.00 ... 19.99%/K (reference temp user-defined)	
	(NLF)	Natural waters to EN 27888 (reference temp +25 °C / +77 °F)	
	(NACL)	Ultrapure water with NaCl traces (0 ... +120 °C / +32 ... +248 °F), reference temp +25 °C / +77 °F	
	(HCL)	Ultrapure water with HCl traces (0 ... +120 °C / +32 ... +248 °F), reference temp +25 °C / +77 °F	
	(NH3)	Ultrapure water with NH3 traces (0 ... +120 °C / +32 ... +248 °F), reference temp +25 °C / +77 °F	
	(NaOH)	Ultrapure water with NaOH traces (0 ... +120 °C / +32 ... +248 °F), reference temp +25 °C / +77 °F	
Concentration determination	-01- NaCl	0 – 26 wt% (0 °C / +32 °F)	... 0 – 28 wt% (+100 °C / +212 °F)
	-02- HCl	0 – 18 wt% (-20 °C / -4 °F)	... 0 – 18 wt% (+50 °C / +122 °F)
	-03- NaOH	0 – 13 wt% (0 °C / +32 °F)	... 0 – 24 wt% (+100 °C / +212 °F)
	-04- H ₂ SO ₄	0 – 26 wt% (-17 °C / +1.4 °F)	... 0 – 37 wt% (+110 °C / +230 °F)
	-05- HNO ₃	0 – 30 wt% (-20 °C / -4 °F)	... 0 – 30 wt% (+50 °C / +122 °F)

Specifications

Concentration determination (continued)	-06- H ₂ SO ₄	94 – 99 wt% (-17 °C / +1.4 °F)	... 89 – 99 wt% (+115 °C / +239 °F)
	-07- HCl	22 – 39 wt% (-20 °C / -4 °F)	... 22 – 39 wt% (+50 °C / +122 °F)
	-08- HNO ₃	35 – 96 wt% (-20 °C / -4 °F)	... 35 – 96 wt% (+50 °C / +122 °F)
	-09- H ₂ SO ₄	28 – 88 wt% (-17 °C / +1.4 °F)	... 39 – 88 wt% (+115 °C / +239 °F)
	-10- NaOH	15 – 50 wt% (0 °C / +32 °F)	... 35 – 50 wt% (+100 °C / +212 °F)

Sensor standardization Input of cell constant with simultaneous display of selected process variable and temperature

Input of conductivity of calibration solution with simultaneous display of cell constant and temperature

Product calibration for conductivity

Temperature probe adjustment

Permitted cell constant 00.0050 ... 19.9999 cm⁻¹

Sensocheck Polarization detection

Delay Approx. 30 s

Sensoface Provides information on the sensor condition

Sensor monitor Direct display of measured values from sensor for validation (resistance/temperature)

USP function Water monitoring in the pharmaceutical industry (USP) with additional limit value (%)

Output via relay contact or HART

I input (TAN)	Current input 0/4 ... 20 mA / 50 Ω for external temperature signal		
Start/end of scale	Configurable -50 ... +250 °C / -58 ... +482 °F		
Characteristic	Linear		
Measurement error ^{1,3)}	< 1% current value + 0.1 mA		
HOLD input	Galvanically separated (optocoupler)		
Function	Switches device to HOLD mode		
Switching voltage	0 ... 2 V AC/DC	HOLD inactive	
	10 ... 30 V AC/DC	HOLD active	
CONTROL input	Galvanically separated (optocoupler)		
Function	Selecting parameter set A/B or flow measurement		
Parameter set A/B	Control input	0 ... 2 V AC/DC 10 ... 30 V AC/DC	Parameter set A Parameter set B
FLOW	Pulse input for flow measurement 0 ... 100 pulses/s		
Message	via 22 mA		
Display	00.0 ... 99.9 l/h		
Output 1	Current loop, 4 ... 20 mA, floating, protected against inverse polarity HART communication (see further below for specifications)		
Supply voltage	14 ... 30 V		
Process variable *	Conductivity, resistivity, concentration, salinity, or temperature		
Characteristic *	Linear, bilinear, or logarithmic		
Overrange *	22 mA in the case of error messages		
Output filter *	PT ₁ filter, time constant 0 ... 120 s		
Measurement error ¹⁾	< 0.25 % current value + 0.025 mA		
Start/end of scale *	Configurable within selected range		
Bilinear: Vertex X/Y *	Configurable within selected range		

Specifications

Output 2	Current loop, 4 ... 20 mA, floating, protected against inverse polarity
Supply voltage	14 ... 30 V
Process variable *	Conductivity, resistivity, concentration, salinity or temperature
Characteristic *	Linear, bilinear, or logarithmic
Overrange *	22 mA in the case of error messages
Output filter *	PT ₁ filter, time constant 0 ... 120 s
Measurement error ¹⁾	< 0.25 % of current value + 0.05 mA
Start/end of scale *	Configurable within selected range
Bilinear: Vertex X/Y *	Configurable within selected range
Real-time clock	Different time and date formats selectable
Power reserve	> 5 days
Display	LC display, 7-segment with icons
Main display	Character height approx. 22 mm, unit symbols approx. 14 mm
Secondary display	Character height approx. 10 mm
Text line	14 characters, 14 segments
Sensoface	3 status indicators (friendly, neutral, sad face)
Mode indicators	meas, cal, conf, diag Further icons for configuration and messages
Alarm indication	Display blinks, red backlighting
Keypad	Keys: meas, menu, info, 4 cursor keys, enter
HART communication	HART version 6 Digital communication by FSK modulation of output current 1 Device identification, measured values, status and messages, parameter setting, calibration, records
FDA 21 CFR Part 11	Access control by editable passcodes Logbook entry and flag via HART in the case of configuration changes Message and logbook entry when enclosure is opened

Diagnostics functions

Calibration data	Calibration date, cell constant
Device self-test	Display test, automatic memory test (RAM, FLASH, EEPROM)
Logbook	100 events with date and time
Extended logbook (TAN)	Audit Trail: 200 events with date and time

Service functions

Sensor monitor	Display of direct sensor signals
Current source	Current specifiable for output 1 and 2 (04.00 ... 22.00 mA)
Passcodes	Assigning passcodes for menu access
Factory setting	Resetting all parameters to factory setting
TAN	Enabling optionally available additional functions

Data retention

Parameters, calibration data, logbook > 10 years (EEPROM)

EMC

EN 61326-1 (General Requirements)

Emitted interference Class B (residential area)

Immunity to interference Industry EN 61326-2-3

Nominal operating conditions

Ambient temperature	-20 ... +65 °C / -4 ... +149 °F
Transport/Storage temperature	-30 ... +70 °C / -22 ... +158 °F
Relative humidity	10 ... 95% not condensing
Supply voltage	14 ... 30 V

Specifications

Enclosure	Molded enclosure made of glass-reinforced PBT, PC
Mounting	Wall, pipe/post or panel mounting
Color	Gray, RAL 7001
Ingress protection	IP 67, NEMA 4X
Flammability	UL 94 V-0
Dimensions	148 mm x 148 mm
Control panel cutout	138 mm x 138 mm to DIN 43 700
Weight	Approx. 1200 g (1600 g incl. accessories and packaging)
Cable glands	3 knockouts for M20 x 1.5 cable glands 2 knockouts for NPT ½" or rigid metallic conduit
Connections	Terminals, conductor cross-section max. 2.5 mm ²
*) User-defined	
2) ± 1 count	1) Acc. to EN 60746, at nominal operating conditions 3) Plus sensor error

Potassium Chloride Solutions

(Conductivity in mS/cm)

Temperature	Concentration ¹		
[°C]	0.01 mol/l	0.1 mol/l	1 mol/l
0	0.776	7.15	65.41
5	0.896	8.22	74.14
10	1.020	9.33	83.19
15	1.147	10.48	92.52
16	1.173	10.72	94.41
17	1.199	10.95	96.31
18	1.225	11.19	98.22
19	1.251	11.43	100.14
20	1.278	11.67	102.07
21	1.305	11.91	104.00
22	1.332	12.15	105.94
23	1.359	12.39	107.89
24	1.386	12.64	109.84
25	1.413	12.88	111.80
26	1.441	13.13	113.77
27	1.468	13.37	115.74
28	1.496	13.62	
29	1.524	13.87	
30	1.552	14.12	
31	1.581	14.37	
32	1.609	14.62	
33	1.638	14.88	
34	1.667	15.13	
35	1.696	15.39	
36		15.64	

1) Data source: K. H. Hellwege (Editor), H. Landolt, R. Börnstein: Zahlenwerte und Funktionen ..., volume 2, part. volume 6

Sodium Chloride Solutions

(Conductivity in mS/cm)

Temperature	Concentration		
[°C]	0.01 mol/l ¹⁾	0,1 mol/l ¹⁾	Saturated ²⁾
0	0.631	5.786	134.5
1	0.651	5.965	138.6
2	0.671	6.145	142.7
3	0.692	6.327	146.9
4	0.712	6.510	151.2
5	0.733	6.695	155.5
6	0.754	6.881	159.9
7	0.775	7.068	164.3
8	0.796	7.257	168.8
9	0.818	7.447	173.4
10	0.839	7.638	177.9
11	0.861	7.831	182.6
12	0.883	8.025	187.2
13	0.905	8.221	191.9
14	0.927	8.418	196.7
15	0.950	8.617	201.5
16	0.972	8.816	206.3
17	0.995	9.018	211.2
18	1.018	9.221	216.1
19	1.041	9.425	221.0
20	1.064	9.631	226.0
21	1.087	9.838	231.0
22	1.111	10.047	236.1
23	1.135	10.258	241.1
24	1.159	10.469	246.2
25	1.183	10.683	251.3
26	1.207	10.898	256.5
27	1.232	11.114	261.6
28	1.256	11.332	266.9
29	1.281	11.552	272.1
30	1.306	11.773	277.4
31	1.331	11.995	282.7
32	1.357	12.220	288.0
33	1.382	12.445	293.3
34	1.408	12.673	298.7
35	1.434	12.902	304.1
36	1.460	13.132	309.5

1) Data source: Test solutions calculated according to DIN IEC 746-3

2) Data source: K. H. Hellwege (Editor), H. Landolt, R. Börnstein: Zahlenwerte und Funktionen ..., volume 2, part. volume 6

Concentration Measurement

Ranges


Substance	Concentration ranges		
NaCl	0-26 wt% (0 °C / +32 °F) 0-26 wt% (+100 °C / +212 °F)		
Configuration	-01-		
HCl	0-18 wt% (-20 °C / -4 °F) 0-18 wt% (+50 °C / +122 °F)	22-39 wt% (-20 °C / -4 °F) 22-39 wt% (+50 °C / +122 °F)	
Configuration	-02-	-07-	
NaOH	0-13 wt% (0 °C / +32 °F) 0-24 wt% (+100 °C / +212 °F)	15-50 wt% (0 °C / +32 °F) 35-50 wt% (+100 °C / +212 °F)	
Configuration	-03-	-10-	
H ₂ SO ₄	0-26 wt% (-17 °C/-1.4 °F) 0-37 wt% (+110 °C/+230 °F)	28-77 wt% (-17 °C/-1.4 °F) 39-88 wt% (+115 °C/+239 °F)	94-99 wt% (-17 °C/-1.4 °F) 89-99 wt% (+115 °C/+239 °F)
Configuration	-04-	-09-	-06-
HNO ₃	0-30 wt% (-20 °C / -4 °F) 0-30 wt% (+50 °C / +122 °F)	35-96 wt% (-20 °C / -4 °F) 35-96 wt% (+50 °C / +122 °F)	
Configuration	-05-	-08-	

For the solutions listed above, the device can determine the substance concentration from the measured conductivity and temperature values in % by wt. The measurement error is made up of the sum of measurements errors during conductivity and temperature measurement and the accuracy of the concentration curves stored in the device. We recommend to calibrate the device together with the sensor, e.g. directly to concentration using the CAL_CELL method. For exact temperature measurement, you should perform a temperature probe adjustment. For measuring processes with rapid temperature changes, a separate temperature probe with fast response should be used.

When measuring processes such as dilution or intensification of CIP solutions (Clean-In-Place), it is helpful to switch between the parameter sets for measuring the process medium and for measuring the CIP solution.

Concentration Curves


-01- Sodium chloride solution NaCl



Conductivity versus substance concentration and process temperature for sodium chloride solution (NaCl)

-02- Hydrochloric acid HCl

-07-




Conductivity versus substance concentration and process temperature for hydrochloric acid (HCl)

Source: Haase/Sauermann/Dücker; Z. phys. Chem. New Edition, Vol. 47 (1965)

Concentration Curves

-03- Sodium hydroxide solution NaOH
-10-




Conductivity versus substance concentration and process temperature for sodium hydroxide solution (NaOH)

-04- Sulfuric acid H_2SO_4

-06-

-09-



Concentration measurement not possible in this range.


Conductivity versus substance concentration and process temperature for sulfuric acid (H_2SO_4)

Source: Darling; Journal of Chemical and Engineering Data; Vol.9 No.3, July 1964

Concentration Curves

-05- Nitric acid HNO_3

-08-




Conductivity versus substance concentration and process temperature for nitric acid (HNO_3)

Source: Haase/Sauermann/Dücker; Z. phys. Chem. New Edition, Vol. 47 (1965)

Error Handling

Alarm condition:

- The display backlighting turns **red**
- The alarm icon  is displayed
- The complete measured-value display blinks
- **"ERR xxx"** is displayed in the lower menu line

Press the [**info**] key to view a short error text:

- The error text appears in the lower menu line
- The main display reads **"InFo"**.

Parameter errors:

Configuration data such as current range, limit values, etc are checked during the input.

If they are out of range,

- **"ERR xxx"** is displayed for 3 sec,
- the display backlighting flashes red,
- the respective maximum or minimum value is shown,
- input must be repeated.

If a faulty parameter arrives through the interface (HART),

- an error message will be displayed: **"ERR 100...199"**
- the faulty parameter can be localized by pressing the [**info**] key

Calibration errors:

If errors occur during calibration,

- an error message will be displayed

Sensoface:

If the Sensoface becomes sad,

- the display backlighting will turn purple
- the cause can be seen by pressing the **info** key
- the calibration data can be seen in the Diagnostics menu

Error Messages

Error	Info text (is displayed in case of fault when the Info key is pressed)	Problem Possible causes
ERR 99	DEVICE FAILURE	Error in factory settings EEPROM or RAM defective This error message only occurs in the case of a total defect. The device must be repaired and recalibrated at the factory.
ERR 98	CONFIGURATION ERROR	Error in configuration or calibration data Memory error in device program Configuration or calibration data defective; completely reconfig- ure and recalibrate the device.
ERR 97	NO MODULE INSTALLED	"MEMOSENS" not selected as sensor type
ERR 96	WRONG MODULE	"MEMOSENS" not selected as sensor type
ERR 95	SYSTEM ERROR	System error Restart required. If error still persists, send in the device for repair.

Error Messages

Error	Info text (is displayed in case of fault when the Info key is pressed)	Problem Possible causes
ERR 10	CONDUCTANCE TOO HIGH	Measuring range of conductance exceeded > 3500 mS
ERR 11	CONDUCTIVITY RANGE CONCENTRATION RANGE SALINITY RANGE	Display range violation Cond > 999.9 mS/cm > 99.99 S/m < 1 ohm * cm Conc > 99.9 % SAL > 45.0 ‰
ERR 13	TEMPERATURE RANGE	Temperature range violation
ERR 15	SENSOCHECK	Sensocheck
ERR 60	OUTPUT LOAD	Load error
ERR 61	OUTPUT 1 TOO LOW	Output current 1 < 3.8 mA
ERR 62	OUTPUT 1 TOO HIGH	Output current 1 > 20.5 mA
ERR 63	OUTPUT 2 TOO LOW	Output current 2 < 3.8 mA
ERR 64	OUTPUT 2 TOO HIGH	Output current 2 > 20.5 mA
ERR 72	FLOW TOO LOW	Flow too low
ERR 73	FLOW TOO HIGH	Flow too high
ERR 108	OUT1 INVALID CORNER X/Y	Bilinear characteristic: Invalid vertex point
ERR 109	OUT2 INVALID CORNER X/Y	

(Sensocheck must have been activated during configuration.)

The smiley in the display (Sensoface) alerts to sensor problems (defective sensor, sensor wear, defective cable, maintenance request). The permitted calibration ranges and the conditions for a friendly, neutral or sad Sensoface are summarized in the following table. Additional icons refer to the error cause.

Sensocheck

Continuously monitors the sensor polarization and the sensor cable capacitance. Critical values make the Sensoface “sad” and the corresponding icon blinks:







The Sensocheck message is also output as error message Err 15. The display backlighting turns red, output current 1 is set to 22 mA (when configured correspondingly). Sensocheck can be switched off during configuration (then Sensoface is also disabled).

Exception:

After a calibration a smiley is always displayed for confirmation.

Note:

The worsening of a Sensoface criterion leads to the devaluation of the Sensoface indicator (Smiley becomes “sad”). An improvement of the Sensoface indicator can only take place after calibration or removal of the sensor defect.

Display	Problem	Status
	Sensor defect	 Wrong or defective sensor, significant polarization of sensor, or excessive cable capacitance (see also error message Err 15).
	Temperature	 Temperature outside range for TC, conc, sal

Conformity with FDA 21 CFR Part 11

In their directive “Title 21 Code of Federal Regulations, 21 CFR Part 11, Electronic Records; Electronic Signatures” the American health agency FDA (Food and Drug Administration) regulates the production and processing of electronic documents for pharmaceutical development and production. This results in requirements for measuring devices used for corresponding applications. The following features ensure that the measuring devices of this Series meet the demands of FDA 21 CFR Part 11:

Electronic Signature – Passcodes

Access to the device functions is regulated and limited by individually adjustable codes – “Passcodes” (see SERVICE). This prevents unauthorized modification of device settings or manipulation of the measurement results. Appropriate use of these passcodes makes them suitable as electronic signature.

Audit Trail

Every (manual) change of device settings can be automatically documented. Each change is tagged with a “Configuration Change Flag”, which can be interrogated and documented using HART communication. Altered device settings or parameters can also be retrieved and documented using HART communication.

Extended logbook

Audit Trail also records function activations (CAL, CONFIG, SERVICE), some Sensoface messages (cal timer, wear) and opening of the enclosure.

Index

A

Access code assignment 94
Access codes, table 128
Accessories 98
Alarm 29
Alarm and HOLD messages 30
Alarm settings 68
Ambulance TAN 94
Assembly 12
Audit Trail 119
Autorange 51

B

Backlighting 21
Block diagram 11
Bootloader version, display 91

C

Calibration 79
Calibration by entry of cell constant 82
Calibration data 88
Calibration errors 114
Calibration, general 26
Calibration modes 79
Calibration, product calibration 83
Calibration solutions 105
Calibration, temp probe adjustment 85
Calibration with calibration solution 80
CD-ROM 3
CIP / SIP 47
Concentration curves: hydrochloric acid HCl 109
Concentration curves: nitric acid HNO₃ 112
Concentration curves: sodium chloride solution NaCl 108
Concentration curves: sodium hydroxide solution NaOH 110
Concentration curves: sulfuric acid H₂SO₄ 111
Concentration ranges 107
Configuration, alarm 68
Configuration, CONTROL input 66

- Configuration, current output 1 50
- Configuration, current output 2 60
- Configuration, general 26
- Configuration, individual settings 39
- Configuration, measuring point 72
- Configuration, menu groups 33
- Configuration, menu structure 32
- Configuration, output current during Error and HOLD 58
- Configuration, overview 35
- Configuration, Sensocheck 68
- Configuration, sensor 42
- Configuration, sensor verification (TAG, GROUP) 48
- Configuration, temperature compensation 62
- Configuration, time and date 72
- Configuration, time averaging filter 56
- Connection to supply units 97
- CONTROL, alarm settings 70
- CONTROL, configuration 66
- CONTROL input 30
- CORRECTION menu 62
- Current output 1, configuration 50
- Current output 2, configuration 60

D

- Date and time (configuration) 72
- Date and time (usage) 73
- Date, display 86
- Device self-test 89
- Device type, display 91
- Diagnostics, calibration data 88
- Diagnostics, device self-test 89
- Diagnostics, general 26
- Diagnostics mode 87
- Diagnostics, sensor monitor 90
- Diagnostics, version 91
- Digital sensors 74
- Digital sensors, connection 75
- Digital sensors, replacement 76

Dimensions 13
Display 21
Display colors 21
Display data in Diagnostics mode 87
Display test 89
Disposal 2
Documentation 3

E

EEPROM test 89
Electronic Signature 119
Enabling an option 94
Enclosure 13
Enclosure components 12
Entering values 23
Error codes 115
Error handling 114
Extended logbook, Audit Trail 119
Extended logbook, diagnostics 90
External temperature measurement 64

F

FDA 21 CFR Part 11 119
FLASH test 89
Flow measurement, alarm 71
Flow measurement, configuration 66
FLOW, monitoring 67

G

GROUP (measuring points) 73

H

HOLD, configuration 59
HOLD mode 28
HOLD mode, exit 28
HOLD mode, external activation 29
HOLD mode, manual activation 29
HOLD mode, output signal 28

I

Info text 115
Installation 16
Intended use 7

K

Keypad 20

L

Logarithmic curve 54
Logbook, diagnostics 90

M

Measured values, display 90
Measuring mode 86
Measuring mode, overview 22
Measuring points (TAG/GROUP) 73
Memosens, connection via RS-485 19
Memosens sensor, configuration 42
Memosens sensors 74
Memosens sensors, connection 75
Memosens sensors, replacement 76
Memosens, wiring example 18
Menu structure 27
Menu structure, configuration 32
Messages (ERR) 115
Message via CONTROL input 31
Monitoring the sensor lines 37
Monitoring the temperature probe 69
Mounting plan 13
Mounting possibilities 7

O

Operating modes 26
Operating mode, selection 23
Operating states 96
Option request: conditions 91
Options, overview 98
Options, TAN 94

Order code 98
Output current, display 86
Output current, fixed value 93
Output current range, configuration 50
Output filter 56
Output signal during HOLD 28
Output signal during HOLD, configuration 59
Overview 7

P

Package contents 12
Package contents, documentation 3
Panel mounting 15
Parameter error 114
Parameter set A/B 33
Parameter set A/B, display 86
Parameter set A/B, individual settings 40
Parameter set A/B, manual selection 34
Parameter set selection via external signal 66
PARSET 67
Passcode assignment 94
Passcodes, table 128
Pipe mounting 14
Power supply units 97
Process variable, range selection 51
Product calibration 83
Product line 98
Protective hood 14

R

RAM test 89
Rating plates 16
Registered trademarks 127
Reset to factory settings 94
Return of products under warranty 2

S

- Safety information 10
- Safety instructions 3
- Selection menu 23
- Sensocheck, configuration 68
- Sensoface 117
- Sensoface, troubleshooting 114
- Sensor connection, assignment 17
- Sensor connection, example 18
- Sensor line monitoring 37
- Sensor monitor, diagnostics 90
- Sensor monitor, service 93
- Sensor type selection 42
- Sensor verification (TAG, GROUP) 49
- Serial number, display 91
- Service, enabling options 94
- Service, factory setting 94
- Service, general 26
- Service mode 92
- Service passcode lost 94
- Service, passcodes 94
- Service, sensor monitor 93
- Service, specifying current outputs 93
- Signal colors 21
- Signal lines 17
- Software version, display 91
- Specifications 99
- Start-up 10
- Supply units 97

T

- Tag number, display 86
- TAG (point of measurement) 73
- TAN options, enabling 94
- TAN options, overview 98
- Technical data 99
- Tempcheck 68
- Temperature compensation 62
- Temperature probe adjustment 85
- Temperature probe, monitoring 69
- Terminal assignments 16
- Terminals, installation 16
- Time and date (configuration) 72
- Time and date (usage) 73
- Time averaging filter 57
- Time, display 86
- Trademarks 127

U

- User interface 20
- USP function 95
- USP function, configuration 43

W

- Weather protector 14
- Wiring 17
- Wiring example 18
- Wiring, power supply units 97

The following names are registered trademarks. For practical reasons they are shown without trademark symbol in this manual.

Stratos®

Sensocheck®

Sensoface®

Memosens® is a registered trademark of Endress+Hauser Conducta GmbH and Knick Elektronische Messgeräte GmbH & Co. KG.

HART® is a registered trademark of the HART Communication Foundation.

Passcodes

In the SERVICE – CODES menu you can assign passcodes to protect the access to certain functions.

Mode of operation	Passcode
Service (SERVICE)	5555
Diagnostics (DIAG)	
HOLD mode	
Calibration (CAL)	
Configuration (CONF)	

Knick
Elektronische Messgeräte GmbH & Co. KG

Beuckestraße 22
14163 Berlin
Germany



Phone: +49 30 80191-0
Fax: +49 30 80191-200
Web: www.knick.de
Email: info@knick.de

Stratos Pro A2.. MSCOND: Memosens Cond Measurement



TA-212.125-MS-KNE03

20161001

Software version: 2.x