Laboratory Meters and Portables



MemoView

MemoView ZU 1059

Mobile tool for the contactless, on-site visualization of Memosens measuring points without a display.

Facts and Features

via Portavo

- Contactless readout of sensor data

the corresponding transmitters

- Direct power supply to MemoView

- One device for all parameters

- Measured value display on site

without process interruption

value recording via Portavo – Predictive maintenance at a glance

diagram and sensor monitor

- Sensor calibration record can be

called up without separating the

sensor from the measuring point

- Saving sensor data via MemoLog

- Data logger function for measured

thanks to graphical display of sensor

when using Memosens sensors and

Mobile Check of Sensor and Measuring Point Without Process Interruption

With MemoView, Memosens online measuring points without on-site display (e.g., in conjunction with MemoGate or MemoRail) can be queried contactless during operation. Users simply push MemoView onto the Memosens sensor connection and all the values and sensor data are displayed on the Portavo mobile analyzer.

Comprehensive Communication

With the Portavo mobile process analyzer, sensor data and up to 10,000 measured values can be recorded and saved directly via MemoLog. This makes it possible to conveniently manage the recorded values everywhere.

Optimized Maintenance

MemoView is ideal for on-site maintenance and read out of calibration data. And in systems with Protos II and Stratos Multi transmitters, MemoView can be used to check the sensors on site.

Product Range

Device Order No. MemoView incl. ZU 1060 cable ZU 1059 Accessories Length Order No. Cable with 2x M8 connector 2.9 m / 9.51 ft ZU 1060

The following devices are suitable for use with MemoView:

Portavo 907 Multi Portavo 908 Multi MemoRail A1401N MemoRail A1405N Protos II 4400

Firmware 01.08.00 or higher Firmware 01.08.00 or higher Firmware 01.04.00 or higher Firmware 01.01.00 or higher Firmware 01.00.00 or higher

1



MemoView ZU 1059

Specifications

Material	MemoView housing	Stainless steel, PVC
	MemoView cable	Sheath: PUR UL
		Screw sleeve M8 plug: brass, nickel-plated
Cable	MemoView cable, 2 x M8 plug	Length: 2.9 m / 9.51 ft
EMC	EN 61326-1	
	Emitted interference	Class A (industrial applications)
	Interference immunity	Industrial applications EN 61326-2-3
RoHS conformity	According to EU directive 2011/65/EU	
Rated operating conditions	Ambient temperature	-20 55 °C / -4 135 °F
	Storage temperature	-25 70 °C / -13 158 °F
	Humidity	10 95 %
	Climatic class	3K5 according to EN 60721-3-3
Degree of protection	IP 65	
Weight	160 g (MemoView)	
	240 g (MemoView + MemoView cable)	
Dimensions	Diameter:	40 mm / 1.75 in
	Height:	80 mm / 3.15 in

Functional Principle

