IsoTrans 600

For isolation and conversion of sinusoidal alternating currents and voltages into standard signals.



The Task

For monitoring mains supplies, control of electric motors etc., alternating currents up to 10 A and voltages up to 800 V are converted to 0(4) ... 20 mA or 0 ... 10 V standard signals.

The Problem

is the provision of several AC/DC transmitters for different ranges. Furthermore, the maintenance staff and the system need to be protected against high potentials.

The Solution

comes in the form of the switchable, signal-powered IsoTrans 600 AC/DC transmitters. Only the transmitters with 4 ... 20 mA output require 230 V AC power supply.

The calibrated range selection for all standard alternating voltages and the 22.5 mm slim modular housing allow for universal use.

The Advantages

The accuracy class is 0.5 – no need to readjust the switchable ranges.

The IsoTrans 600 provides protective separation up to 600 V AC/DC according to EN 61010-1.

This allows for use in 3-phase networks without the need for further measures to ensure protective separation.

Except for the 4 ... 20 mA output, the IsoTrans 600 is supplied directly from the measurement signal. There are no costs for a power supply and wiring.

Optimized circuit design makes the power consumption and the resulting self-heating very low. This protects against unnecessary temperature-related component aging and thus increases reliability.

The Technology

The measured values are converted into rms values through averaging, in the case of sinusoidal input signals with calibration. Short rise times, very low residual ripple and excellent overload behavior guarantee maximum transmission quality.

Knick >

The Facts

- Calibrated range selection
 Simple inventory management due to universal application possibilities, no need for complicated
 readjustment
- No power supply required for models with 0 ... 20 mA and 0 ... 10 V output
 Minimal wiring effort and no mains

influences

 Protective separation according to EN 61140
 Protection of the maintenance staff

and subsequent devices against excessively high voltages

- 22.5-mm modular housing
 Low space requirement due to compact design
- High long-term stability and accuracy
 Reliable operation without recalibration

- Very low power consumption allows for minimum ratings of the upstream current and voltage transformer
- Very low self-heating
 No temperature-related component aging, high MTBF
- Maximum reliability
 No repair or failure costs
- High reliability
- 5-year warranty





IsoTrans 600

Product Line

Г

IsoTrans 600 with current			
input	Input	Output	Order No.
IsoTrans 611/-1	0 1 A	0 20 mA	611-1 A2
lsoTrans 621-1			
(with power supply)	0 1 A	4 20 mA	621-1 A2
IsoTrans 631/-1	0 1 A	0 10 V	631-1 A2
IsoTrans 615/-1	0 5 A	0 20 mA	615-1 A2
lsoTrans 625-1			
(with power supply)	0 5 A	4 20 mA	625-1 A2
IsoTrans 635/-1	0 5 A	0 10 V	635-1 A2
soTrans 600 with voltage			

input Order No. IsoTrans 647/-2 0...100/120 V switchable 0...20 mA/0...10 V, terminal selectable 647-2 A2 IsoTrans 648/-2 0...250/400 V switchable 0...20 mA/0...10 V, terminal selectable 648-2 A2 IsoTrans 650-2 0...100/120/250/400 V, 0...20 mA/0...10 V, terminal selectable 650-2 A2 (with power supply) terminal selectable switchable / terminal selectable 650-2 A2

Power supply

621-1, 625-1, 650-2: 230 V AC; other: none, supply from input signal

Options	Order No.
lsoTrans 635-1 and IsoTrans 650-2 for input frequency 16 2/3 Hz	
(635-1: response time 1 s, load ≥7.5 kohms)	469

Selection Aid

Selection Ald		Output		
		0 20 mA	4 20 mA	0 10 V
Input	0 1 A AC	611-1 A2	621-1 A2*)	631-1 A2
	0 5 A AC	615-1 A2	625-1 A2*)	635-1 A2
	0 100 V AC	647-2 A2 650-2 A2*)	l 650-2 A2*)	647-2 A2 650-2 A2*)
	0 120 V AC	647-2 A2 650-2 A2*)	650-2 A2*)	647-2 A2 650-2 A2* ⁾
	0 250 V AC	648-2 A2 650-2 A2*)	650-2 A2*)	648-2 A2 650-2 A2* ⁾
	0 400 V AC	648-2 A2 650-2 A2 ^{*)}	650-2 A2*)	648-2 A2 650-2 A2* ⁾

Knick >

Specifications

Input data	IsoTrans 600 with current input		IsoTrans 600 with voltage input			
	6x1		6x5	647	648	650
Input ¹⁾	0 20 mA 0 1 A 48 63 Hz		0 10 V 0 5 A 48 63 Hz	0100/120V switchable, measurements from 10% FS 4863 Hz	0 250/400V switchable, measurements from 10 % FS 48 63 Hz	0100/120/ 250/400 V terminal selectable 4863 Hz
Overload capacity	Continuous: 2 times I _{nom} 1 s: 50 times I _{nom}		Continuous: 1.5 times V _{nom} 1 s: 4 times V _{nom}			
Input power at nominal current	Approx. 1 VA		Max. 0.4 VA			
Output data	IsoTrans 600 with current input		IsoTrans 600 with voltage input			
l	61x	62x	63x	647	648	650
Output	0 20 mA	4 20 mA	0 10 V	0 20 mA/ 0 10 V terminal selectable		0(4) 20 mA / 0(2) 10 V switch/termina selectable
Load	≤750 ohms		≥2 kohms			
Response time (T ₉₀) Load 0 ohm Load 750 ohms	Approx. 0.1 s Approx. 0.2 s		< 0.2 s	Approx. 0.25 s		
Transmission behavior						
Transmission error	Class 0.5 (EN 60688)					
Power supply						
Power supply (only models with 4 20 mA output)	230 V AC –15 47 63 Hz, a		soTrans 650 approx	. 1.5 VA)		
Isolation						
Galvanic isolation	With power so Without powe	,	3-port isolation between input, output and power supply Isolation between input and output			,
Test voltage	With current i With voltage		6 kV AC for models with power supply: 6 kV AC (input against output / power supply), 4 kV AC (output against power supply) 4 kV AC			
Protection against electric shock	Protective separation according to EN 61140 by reinforced insulation according to EN 61010-1. Working voltages at overvoltage category II and pollution degree 2: up to 400 V AC/DC across output and power supply. up to 600 V AC/DC across input and output and, if applicable, power supply (current isolators up to category III, degree 2). For applications with high working voltages, ensure there is sufficient spacing or isolation from neighboring devices and protection against electric shocks.					

IsoTrans 600

Standards and approvals		
Surge withstand	5 kV 1.2/50 μs according to IEC 255-4	
EMC	89/336/EEC, EN 61326	
Further data		
Ambient temperature	Operation: -10 +70 °C	
	Transport and storage: -30 +80 °C	
Design	Modular housing A7, 22.5 mm wide, screw terminals	
	See dimension drawings for further measurements	
Ingress protection	l Housing: IP 40, terminals: IP 20	
Mounting	Snap-on mounting for 35 mm mounting rail according to EN 50022 or screw fastener M4	
	See dimension drawing for conductor cross-section	
Weight	бхх-1: арргох. 350 g	
-	6xx-2: approx. 250 g	


 $^{1)}$ other input values up to 10 A or 800 V in the frequency range of 16 \ldots 63 Hz upon request

Knick >


Block Diagrams

Г

AC/DC Transmitter with Current Input




AC/DC Transmitter with Voltage Input





IsoTrans 600


Dimension Drawings and Terminal Assignments



Г







Snap-on mounting onto 35-mm EN 50022 mounting rail

All dimensions in mm

AC/DC transmitter with current input 6**-1

1	Input	~	
2	Input	~	

5 Output +

- 6 Output _
- 7 Power supply ſ
- 8 Power supply

(only for models 621 and 625, nothing connected otherwise)

AC/DC transmitter with voltage input 647-2 and 648-2

1 Input ~ 2 Input ~

5	Output	+	20 mA
6	Output	_	

7 Output + 10V Mounting screws M 2,5 x 8 with self-raising locking plates, max. conductor cross-section 2 x 2.5 mm² solid or 2 x 1.5 mm² stranded with ferrule

AC/DC transmitter

1 Input

9 Input

5

2 Input

7

3

4

Input

Output

11 Output

10 Input

with voltage input 650-2

0

_

Output + 10 V

Power supply ~

8 Power supply ~

100 V ~

120 V ~

250 V ~

400 V ~

+ 20 mA

258

Screw mounting with extendable lugs