



SE565 pH Sensor



All dimensions in millimeters [inches]

Installation position



- 1 Memosens connector
- 2 Ring for Ex marking
- 3 Hexagon screw A/F 19 with serial number
- 4 Connection PG 13.5
- 5 PVDF compression ring
- 6 O-ring 11.5 x 2.6 mm EPDM-FDA
- 7 Nameplate
- 8 Junction
- 9 Sensor tip
- 10 Permitted installation position
- 11 Prohibited installation position

Safety

This document contains important instructions for the use of the product. Always follow all instructions and operate the product with caution. If you have any questions, please contact Knick Elektronische Messgeräte GmbH & Co. KG (hereinafter sometimes referred to as "Knick") using the information provided on the back page of this document.

Hazards due to pressure, temperature, aggressive media, or explosive atmospheres are possible, depending on the location of use.

Intended Use

The SE565 sensor (hereafter also called "product") is used for continuous ORP measurement in aqueous process media.

SE565X/*-NMSN-** Digital ORP measurement

Use of the product is only permitted in compliance with the operating conditions stated in the Specifications.

The measurement data of the sensor are output via a suitable industrial transmitter.

THE OPERATING COMPANY SHALL BE SOLELY RESPONSIBLE FOR ANY DAMAGES RESULTING FROM OR ARISING OUT OF AN UNINTENDED USE OF THE PRODUCT.

Personnel Requirements

The operating company shall ensure that any personnel using or otherwise interacting with the product is adequately trained and has been properly instructed.

The operating company shall comply and cause its personnel to comply with all applicable laws, regulations, codes, ordinances and relevant industry qualification standards related to product.

Hazardous Substances

IN THE EVENT OF ANY CONTACT WITH HAZARDOUS SUBSTANCES OR OTHER INJURY HEREUNDER, SEEK IMMEDIATE MEDICAL ATTENTION OR FOLLOW APPLICABLE PROCEDURES TO ADDRESS HEALTH AND SAFETY OF PERSONNEL. FAILURE TO SEEK IMMEDIATE MEDICAL ATTENTION MAY RESULT IN SERIOUS INJURY OR DEATH.

In certain situations, e.g., sensor replacement or cleaning, personnel may come into contact with the following hazardous substances:

- Process medium
- Cleaning medium

The operating company is responsible for conducting a job hazard analysis.

See the relevant manufacturers' safety datasheets for hazard and safety instructions on handling hazardous substances.

Operation in Hazardous Locations

The SE565X sensor is certified for operation in hazardous locations.

Memosens Ex sensors are marked by an orange-red ring.

Observe all applicable local and national codes and standards for the installation of equipment in explosive atmospheres. For further guidance, consult the following:

- IEC 60079-14
- EU directives 2014/34/EU and 1999/92/EC (ATEX)
- NFPA 70 (NEC)
- ANSI/ISA-RP12.06.01

The electrical and thermal parameters of the sensors must be adhered to.

Electrical and Thermal Parameters

Certificate Number	Marking
IECEx DEK 22.0019X	Ex ia IIC T6...T3 Ga Ex ia IIIC T ₂₀₀ 135 °C Da
JPEX DEK 24.0039X	Ex ia Ga IIC T4

The electrical and thermal parameters as well as the special conditions for installation and operation in hazardous locations are indicated on the enclosed Control Drawing 213.215-066.

Product

Package Contents

- SE565 with watering cap
- User Manual
- Control Drawing
- Quality Certificate
- EU Declaration of Conformity

Product Identification

SE565X/1 - NMSN - B1	Model designation
	Internal marking
	Connector
	MS: Memosens connector
	Length
	1: 120 mm (4.72')
	2: 225 mm (8.86')
	Ex approval
	X: yes

Product Characteristics

- Platinum sensor tip
- Ceramic junction
- Gel electrolyte, pressurized
- Integrated temperature detector


Note: The temperature detector measures the temperature as secondary measured value. This measurement is primarily intended for automatic compensation of the measured value and not for regulating and controlling the process temperature.

The sensor's identification and calibration data is stored in the Memosens connector. The data communication of the Memosens sensors takes place exclusively via a compatible meter.

Nameplate

The SE565 sensor is labeled with a nameplate on the sensor body.

Example:



1 Approval information ¹⁾	5 Memosens logo
2 Measuring range	6 CE mark with test number
3 Product designation	7 Permitted pressure and temperature range
4 Manufacturer and address	8 Special conditions and danger points

Item number/serial number/product date in form *****/*****/YYWW are printed on the packaging.

Refer to the packaging for more information on approvals and disposal.

¹⁾ For details, see nameplate



Installation

⚠ CAUTION! Risk of cutting injuries from broken sensor glass. Handle the sensor with care.

01. Check the SE565 sensor for damage.
Note: Do not use damaged sensors.
02. Remove the watering cap.
03. Briefly rinse the sensor with pure water and pat dry.
04. Install the sensor at the installation location.
05. Align the junction in the process flow direction.
06. Connect the sensor to the sensor cable²⁾ and connect the sensor cable to a measuring device³⁾.

Operation

When operating in a hazardous location, observe the electrical and thermal parameters of the Control Drawing.

01. Clean the sensor after every work cycle.
Note: Adjust the cleaning intervals to the operating conditions.
02. During work breaks or interruptions in measurement, store the sensor in the watering cap filled with electrolyte (3 mol/l KCl).
Note: Do not allow process media to dry on the sensor tip and junction.

Cleaning

⚠ CAUTION! Injury due to the use of aggressive cleaning agents. Handle aggressive cleaning agents with care; wear protective equipment if necessary. Observe safety instructions.

Clean the sensor in case of soiling and deviations in slope, zero point, and/or response time.

01. Remove soiling with an appropriate cleaning agent.
02. Rinse the sensor with demineralized water.

Recommended Cleaning Agents

Contamination	Cleaning Medium
Water-soluble substances	Water
Greases and oils	Warm water and household dishwashing liquid
Lime and hydroxide deposits	Acetic acid (5 %) or hydrochloric acid (1 %)
Protein	Pepsin/HCl solution
Silver sulfide	Thiourea/HCl solution

Calibration

Before calibration, remove the sensor if necessary. For ORP measurement, 1-point calibration is recommended.

Carry out calibration in accordance with the user manual of the measuring device.

Sterilizing

For application in sterile processes such as fermentation, sterilize the sensor before starting the operating cycle.

Sterilization can be effected in situ with steam or superheated process medium.

Removal

⚠ WARNING! For process media that contain hazardous substances: The sensor has direct contact with the process medium. Rinse and clean the SE565 after removing it from the process medium. Follow the information on hazardous substances.

01. Depressurize the process and discharge if necessary.
02. Disconnect the sensor from the sensor cable.
03. Remove the sensor from the fitting.
04. Clean and store the sensor.

Storage

Immerse the sensor tip and junction into the watering cap with electrolyte (3 mol/l KCl) and store. If the sensor is unintentionally stored dry, water the sensor in electrolyte (3 mol/l KCl) for several hours.

Disposal

To dispose of the product properly, follow the local regulations and laws.



Waste devices must be separated from unsorted municipal waste before disposal.

Information on return and recycling can be found in the manufacturer's declaration on our website.

Specifications

Measuring range	
pH	±1500 mV
Process temperature	0 ... 135 °C (32 ... 275 °F)
Process pressure	-1 ... 6 bar (-14.5 ... 87 psi)
Temperature detector	NTC 30 kΩ
Wetted materials	
Body	Glass
Junction	1× ceramic
Electrolyte	Gel, pressurized
Sensor tip	Platinum
Reference system	Ag/AgCl with silver ion trap
Process connection	PG 13.5
Tightening torque	1 ... 3 Nm
Electrical connection	Memosens connector
Dimensions	See graphic

Translation of the original instructions
Copyright 2025 • Subject to change

Version 1

This document was published on January 15, 2025.

The latest documents are available for download on our website under the corresponding product description.

TA-300.025-200-KNEN01



104168

²⁾ See Control Drawing for information on the certified Memosens cable.

³⁾ Observe the instructions for use relating to the measuring device.